



Synway SMG Series Digital Gateway

SMG2030

SMG2060

SMG2120

SMG3008

SMG3016

Digital Gateway

User Manual

Version 1.6.2

Synway Information Engineering Co., Ltd

www.synway.net

Content

Content	i
Copyright Declaration.....	iv
Revision History.....	v
Chapter 1 Product Introduction	1
1.1 Typical Application	1
1.2 Feature List.....	2
1.3 Hardware Description	3
1.4 Alarm Info	5
Chapter 2 Quick Guide	6
Chapter 3 WEB Configuration.....	12
3.1 System Login	12
3.2 Operation Info	14
3.2.1 System Info.....	14
3.2.2 PSTN Status.....	16
3.2.3 SS7 Server	19
3.2.4 Call Monitor.....	23
3.2.5 Call Count.....	24
3.3 SIP Settings	25
3.3.1 SIP Settings	26
3.3.2 SIP Trunk	29
3.3.3 SIP Register.....	32
3.3.4 SIP Account	35
3.3.5 SIP Trunk Group	37
3.3.6 Media Settings.....	40
3.4 PCM Settings.....	42
3.4.1 PSTN.....	43
3.4.2 Circuit Maintenance	45
3.4.3 PCM.....	45
3.4.4 PCM Trunk.....	48
3.4.5 PCM Trunk Group	50
3.4.6 Number-receiving Rule	52
3.4.7 Reception Timeout.....	55
3.5 SS7 Settings	56
3.5.1 SS7.....	57
3.5.2 TUP	58
3.5.3 TUP Number Parameter	59
3.5.4 ISUP	61
3.5.5 ISUP Number Parameter	63
3.5.6 Original CalleeID Pool	66
3.5.7 Redirecting Number Pool (Hidden item)	67
3.5.8 SS7 Server	69

3.6	ISDN Settings	75
3.6.1	ISDN	76
3.6.2	Number Parameter	78
3.6.3	Redirecting Number (Hidden item)	79
3.6.4	Add Gateway	79
3.7	SS1 Settings	81
3.8	Fax Settings	82
3.8.1	Fax	82
3.9	Route Settings	84
3.9.1	Routing Parameters	84
3.9.2	IP to PSTN	84
3.9.3	PSTN to IP	86
3.10	Number Filter	88
3.10.1	Whitelist	89
3.10.2	Blacklist	91
3.10.3	Number Pool	91
3.10.4	Filtering Rule	93
3.11	Number Manipulation	96
3.11.1	IP to PSTN CallerID	96
3.11.2	IP to PSTN CalleeID	99
3.11.3	IP to PSTN Original CalleeID	100
3.11.4	PSTN to IP CallerID	100
3.11.5	PSTN to IP CalleeID	103
3.11.6	PSTN to IP Original CalleeID	104
3.11.7	CallerID Pool	104
3.12	System Tools	106
3.12.1	Network	108
3.12.2	Management	109
3.12.3	IP Routing Table	110
3.12.4	SNMP Config	112
3.12.5	Radius	113
3.12.6	Configuration File	115
3.12.7	Signaling Capture	116
3.12.8	Signaling Call Test	117
3.12.9	Signaling Call Track	118
3.12.10	PING Test	119
3.12.11	TRACERT Test	120
3.12.12	Modification Record	121
3.12.13	Backup & Upload	122
3.12.14	Factory Reset	122
3.12.15	Upgrade	123
3.12.16	Change Password	123
3.12.17	Device Lock	124
3.12.18	Restart	125
Chapter 4	Typical Applications	126
4.1	Application 1	126
4.1.1	Configurations for Headquarters	127
4.1.2	Configurations for Branch A	129
4.1.3	Configurations for Branch B	132
4.2	Application 2	135
4.2.1	Configurations for Headquarters	136
4.2.2	Configurations for Branches	138
Appendix A	Technical Specifications	139

Appendix B Troubleshooting	140
Appendix C ISUP (ISDN) Pending Cause to SIP Status Code	141
Appendix D TUP Pending Cause to SIP Status Code	143
Appendix E Technical/sales Support	144

Copyright Declaration

All rights reserved; no part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Synway Information Engineering Co., Ltd (hereinafter referred to as 'Synway').

Synway reserves all rights to modify this document without prior notice. Please contact Synway for the latest version of this document before placing an order.

Synway has made every effort to ensure the accuracy of this document but does not guarantee the absence of errors. Moreover, Synway assumes no responsibility in obtaining permission and authorization of any third party patent, copyright or product involved in relation to the use of this document.

Revision History

Version	Date	Comments
Version 1.3.0	2014-06	Initial publication.
Version 1.3.1	2014-08	New revision
Version 1.3.2	2014-10	New revision
Version 1.5.0	2014-12	Add description on the new series SMG3016
Version 1.5.1	2015-01	Add description on the new series SMG3008
Version 1.6.0	2015-03	New revision
Version 1.6.1	2015-06	New revision
Version 1.6.2	2015-09	New revision

Note: Please visit our website <http://www.synway.net> to obtain the latest version of this document.

Chapter 1 Product Introduction

Thank you for choosing Synway SMG Series Digital Gateway!

The Synway SMG series digital gateway products (hereinafter referred to as 'SMG digital gateway') are mainly used for connecting PSTN or enterprise PBX with the IP telephony network or IP PBX. It provides a powerful, reliable and cost-effective VoIP solution for such occasions as IP call centers and multi-branch agencies.

The SMG series digital gateway has five models:

- SMG2030: 1 E1/T1 interface (30 digital ports)
- SMG2060: 2 E1/T1 interfaces (60 digital ports)
- SMG2120: 4 E1/T1 interfaces (120 digital ports)
- SMG3008: 8 E1/T1 interfaces (240 digital ports)
- SMG3016: 16 E1/T1 interfaces (480 digital ports)

1.1 Typical Application




Figure 1-1 Typical Application

1.2 Feature List

Basic Features	Description
<i>PSTN Call</i>	Call initiated from PSTN to a designated SIP trunk, via routing and number manipulation.
<i>IP Call</i>	Call initiated from IP to a designated PCM trunk, via routing and number manipulation.
<i>Number Manipulation</i>	Peels off some digits of a phone number from left/right, or adds a prefix/suffix to a phone number.
<i>PSTN/ VoIP Routing</i>	Routing path: from IP to PSTN or from PSTN to IP.
<i>Fax</i>	Multiple fax parameters: fax mode, maximum fax rate, fax train mode, error correction mode, etc.
<i>Echo Cancellation</i>	Provides the echo cancellation feature for a call conversation.
Signaling & Protocol	Description
<i>SS7</i>	SS7-TUP, SS7-ISUP
<i>ISDN</i>	ISDN User Side, ISDN Network Side
<i>SS1</i>	SS1 Signaling
<i>SIP Signaling</i>	Supported protocol: SIP V1.0/2.0, RFC3261
<i>Voice</i>	CODEC G.711A, G.711U, G.729A/B, G723, G722, AMR, iLBC DTMF Mode RFC2833, SIP INFO, INBAND
<i>Fax</i>	Fax Mode T.38, Pass-Through Baud Rate 14400bps, 9600bps, 4800bps
Network	Description
<i>Network Protocol</i>	Supported protocol: TCP/UDP, HTTP, ARP/RARP, DNS, NTP, TFTP, TELNET, STUN
<i>Static IP</i>	IP address modification support
<i>DNS</i>	Domain Name Service support
Security	Description
<i>Admin Authentication</i>	Support admin authentication to guarantee the resource and data security
Maintain & Upgrade	Description
<i>WEB Configuration</i>	Support of configurations through the WEB user interface
<i>Language</i>	Chinese, English
<i>Software Upgrade</i>	Support of user interface, gateway service, kernel and firmware upgrades based on WEB
<i>Tracking Test</i>	Support of Ping and Tracert tests based on WEB

SysLog Type

Three options available: ERROR, WARNING, INFO

1.3 Hardware Description

The SMG digital gateway features 1U rackmount design and integrates embedded LINUX system within the POWERPC+DSP hardware architecture. It has 1/2/4/8/16 E1/T1 ports and 2 Kilomega-Ethernet ports (LAN1 and LAN2) on the chassis.

(a) See below figures for SMG2000 series appearance:



Figure 1-2 Front View



Figure 1-3 Rear View



Figure 1-4 Left View

(b) See below figures for SMG3000 series appearance:




Figure 1-5 Front View



Figure 1-6 Rear View

Note: The left view for SMG3000 series is same as that for SMG2000 series, refer to Figure 1-4.

The table below gives a detailed introduction to the interfaces, buttons and LEDs illustrated above:

Interface	Description
LAN	Amount: 2
	Type: RJ-45
	Bandwidth: 10/100/1000Mbps
	Self-Adaptive Bandwidth Supported
	Auto MDI/MDIX Supported
E1/T1	Amount: 1/2/4/8/16
	Type: RJ-45
Console Port	Amount: 1
	Type: RS-232
	Baud Rate: 115200 bps
	Connector: RJ45 (See Figure 1-7 for signal definition)
	Data Bits: 8 bits
	Stop Bit: 1 bit
	Parity Unsupported
	Flow Control Unsupported
Button	Description
Power Key	Power on/off the SMG digital gateway. You can turn on the two power keys at the same time to have the power supply working in the hot-backup mode.
Reset Button	Restore the gateway to factory settings.
LED	Description
Power Indicator	Indicates the power state. It lights up when the gateway starts up with the power cord well connected.
Run Indicator	Indicates the running status. For more details, refer to 1.4 Alarm Info .
Alarm Indicator	Alarms the device malfunction. For more details, refer to 1.4 Alarm Info .
Link Indicator	The green LED on the left of LAN, indicating the network connection status.
ACT Indicator	The orange LED on the right of LAN, whose flashing tells data are being transmitted.
E1/T1 Indicators	The green LED on the right of E1/T1 interface lights up and keeps on after the E1/T1 module is successfully synchronized.

Channel Indicators	Indicates the synchronization status of E1/T1 channels. It will light up and keep on if E1/T1 is synchronized; otherwise, it will go out.
---------------------------	---

Note: The console port is used for debugging. While connection, the transmitting and receiving lines of the gateway and the remote device should be cross-linked. That is, connect the transmitting line of the gateway to the receiving line of the remote device, and vice versa. The figure below illustrates the signal definition of the console port on the gateway.




Figure 1-7 Console Port Signal Definition

For other hardware parameters, refer to [Appendix A Technical Specifications](#).

1.4 Alarm Info

The SMG digital gateway is equipped with two indicators denoting the system's running status: Run Indicator (green) and Alarm Indicator (red). The table below explains the states and meanings of the two indicators.

LED	State	Description
Run Indicator	Go out	System is not yet started.
	Light up	System is starting.
	Flash	Device is running normally.
Alarm Indicator	Go out	Device is working normally.
	Light up	Upon startup: Device is running normally. In runtime: Device goes abnormal.
	Flash	System is abnormal.

Note:

- The startup process consists of two stages: System Booting and Gateway Service Startup. The system booting costs about 1 minute and once it succeeds, both the run indicator and the alarm indicator light up. Then after the gateway service is successfully started and the device begins to work normally, the run indicator flashes and the alarm indicator goes out.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our technicians for help. Go to [Appendix E Technical/sales Support](#) to find the contact way.

Chapter 2 Quick Guide

This chapter is intended to help you grasp the basic operations of the SMG digital gateway in the shortest time.

Step 1: Confirm that your packing box contains all the following things.

- SMG Series Digital Gateway *1
- Angle Bracket *2, Rubber Foot Pad *4, Screw for Angle Bracket *8
- 220V Power Cord *2
- Warranty Card *1
- Installation Manual *1

Step 2: Properly fix the SMG digital gateway.

If you do not need to place the gateway on the rack, simply fix the 4 rubber foot pads. Otherwise, you should first fix the 2 angle brackets onto the chassis and then place the chassis on the rack.

Step 3: Connect the power cord.

Make sure the device is well grounded before you connect the power cord. Check if the power socket has the ground wire. If it doesn't, use the grounding stud on the rear panel of the device (See Figure 1-3) for earthing.

Note: Each SMG digital gateway has two power interfaces to meet the requirement for power supply hot backup. As long as you properly connect and turn on these two power keys, either power supply can guarantee the normal operation of the gateway even if the other fails.

Step 4: Connect the network cable.

Step 5: Connect the E1/T1 trunk. Connect the E1/T1 interface of the digital gateway to that of the remote device by E1/T1 trunk. After connection, check if the synchronization indicator (green LED) is lit and keeps on, which indicates that the E1/T1 trunk is well connected and the E1/T1 module is successfully synchronized.

For the 75Ω-unbalanced coaxial cable, in consideration of various line conditions, each PCM on the digital gateway is equipped with two grounding jumpers which respectively control the grounding of the transmitting and the receiving end. Under normal condition, that is, the chassis of the gateway is well grounded, the grounding jumpers at the receiving end should be disconnected and the ones at the transmitting end should be short-circuited. This configuration is the factory default setting and applicable in most situations so that there is usually no need to change it. For the 120Ω-balanced twisted pair cable, the grounding jumpers at both ends should be disconnected.

You can construct an E1 trunk according to Figure 2-1. Prevent reverse connection of the transmitting and receiving lines. The state of the receiving line can be checked by the synchronization indicator (green LED) of the E1 interface. When the receiving line is in a normal state, the indicator is lit and keeps on. If the indicator is off or flashing, it means that the connection of the receiving line may probably be reversed. However, the state of the transmitting line can only be examined by the opposite terminal. The synchronization indicator starts working only after the device is powered on and successfully initialized.




Figure 2-1 Pin Layout for E1 Interface

Step 6: Log in the gateway.

Enter the original IP address (LAN 1: 192.168.1.101 or LAN 2: 192.168.0.101) of the SMG digital gateway in the browser to go to the WEB interface. The original username and password of the gateway are both 'admin'. For detailed instructions about login, refer to [3.1 System Login](#). We suggest you change the initial username and password via 'System Tools → Change Password' on the WEB interface as soon as possible after your first login. For detailed instructions about changing the password, refer to [3.12.16 Change Password](#). After changing the password, you are required to log in again.

Step 7: Modify IP address of the gateway.

You can modify the IP address of the gateway via 'System Tools → Network' on the WEB interface to put it within your company's LAN. Refer to [3.12.1 Network](#) for detailed instructions about IP modification. After changing the IP address, you shall log in the gateway again using your new IP address.

Step8: Set PCM.

On your initial use of the SMG digital gateway, you shall enter the PCM interface and set the configuration items 'Signaling Protocol' and 'Interface'. These items must be in conformity with the physical connection. You may use the default values of other configuration items. Refer to [3.4.3 PCM](#) for detailed instructions about PCM Settings.

Note: You shall restart the service to validate the settings in this step. Refer to [3.12.18 Restart](#) for detailed instructions.

Step 9: Configure signaling protocol parameters.

Further configure the signaling protocol you set in Step 8. Different protocols are configured on different interfaces. See below for detailed instructions.

● SS7-ISUP:

Note: For your easy understanding and manipulation, this step does not involve the ISUP quasi-associated mode configuration and the dual gateway feature. For descriptions about these configurations, refer to [3.5 SS7 Settings](#).

The configuration interfaces related to SS7-ISUP include: [SS7](#), [ISUP](#) and [SS7 Server](#).

On your initial use of the SMG digital gateway, you may adopt the default values of the configuration items on the [SS7](#) and [ISUP](#) interfaces. Note that the [SS7 Server](#) interface must be configured properly. Otherwise, the PSTN trunks may be unavailable. Follow the instructions here to configure the SS7 Server:

- Step 1: Set OPC, Server IP and Signaling Point Code Standard. The OPC is generally allocated by the central office. The Server IP is the IP address of the SS7 server and you may use its default value. The Signaling Point Code Standard, which varies on the PBX model, can be set to 24 or 14. After modification, click the 'Modify' button on the right to save the settings.
- Step 2: Modify the current link or click the 'Add New' button below the signaling link list to add a new link. Enter the physical address of the actually used signaling PCM (E1 interface) and click 'Save' to save the modification. If only one PCM is used for signaling in the gateway, you need just configure one signaling link.
- Step 3: Modify the current linkset or click the 'Add New' button below the signaling linkset list to add a new linkset. You shall select the link configured in Step 2 for 'Link' and use the default values for the other configuration items. After modification, click 'Save'.
- Step 4: Modify the current DPC or click the 'Add New' button below the DPC list to add a new DPC. Fill in 'SP Code' with the signaling point code of the remote end (i.e. signaling destination), select the linkset configured in Step 3 for 'Linkset' and use the default values for the other configuration items. After modification, click 'Save'.

Step 5: Modify the current CIC routing rule or click the 'Add New' button below the ISUP_CIC routing rule list to add a new CIC routing rule. Select the DPC configured in Step 4 for 'DPC', fill in 'CIC_PCM' according to the actual allocation and use the default values for the other configuration items. After modification, click 'Save'. Note that if multiple PCMs in the gateway are used for voice transmission, they should be configured with multiple CIC routing rules accordingly.

Note: After configuring SS7-ISUP related interfaces, you shall restart the service to validate the settings. Refer to [3.12.18 Restart](#) for detailed instructions.

- **SS7-TUP:**

Note: For your easy understanding and manipulation, this step does not involve the TUP quasi-associated mode configuration and the dual gateway feature. For descriptions about these configurations, refer to [3.5 SS7 Settings](#).

The configuration interfaces related to SS7-TUP include: [SS7](#), [TUP](#) and [SS7 Server](#).

On your initial use of the SMG digital gateway, you may adopt the default value of the configuration items on the [SS7](#) and [TUP](#) interfaces. Note that the [SS7 Server](#) interface must be configured properly. Otherwise, the PSTN trunks may be unavailable. Follow the instructions here to configure the SS7 Server:

- Step 1: Set OPC, Server IP and Signaling Point Code Standard. The OPC is generally allocated by the central office. The Server IP is the IP address of the SS7 server and you may use its default value. The Signaling Point Code Standard, which varies on the PBX model, can be set to 24 or 14. After modification, click the 'Modify' button on the right to save the settings.
- Step 2: Modify the current link or click the 'Add New' button below the signaling link list to add a new link. Enter the physical address of the actually used signaling PCM (E1 interface) and click 'Save' to save the modification. If only one PCM is used for signaling in the gateway, you need just configure one signaling link.
- Step 3: Modify the current linkset or click the 'Add New' button below the signaling linkset list to add a new linkset. You shall select the link configured in Step 2 for 'Link' and use the default values for the other configuration items. After modification, click 'Save'.
- Step 4: Modify the current DPC or click the 'Add New' button below the DPC list to add a new DPC. Fill in 'SP Code' with the signaling point code of the remote end (i.e. signaling destination), select the linkset configured in Step 3 for 'Linkset' and use the default values for the other configuration items. After modification, click 'Save'.
- Step 5: Modify the current CIC routing rule or click the 'Add New' button below the TUP_CIC routing rule list to add a new CIC routing rule. Select the DPC configured in Step 4 for 'DPC', fill in 'CIC_PCM' according to the actual allocation and use the default values for the other configuration items. After modification, click 'Save'. Note that if multiple PCMs in the gateway are used for voice transmission, they should be configured with multiple CIC routing rules accordingly.

Note: After configuring SS7-TUP related interfaces, you shall restart the service to validate the settings. Refer to [3.12.18 Restart](#) for detailed instructions.

- **ISDN User Side/Network Side:**

The configuration interface related to ISDN User Side/Network Side is [ISDN](#). On your initial use of the SMG digital gateway, you may adopt the default value of the configuration items on this interface.

Note: After configuring the ISDN interface, you shall restart the service to validate the settings. Refer to [3.12.18 Restart](#) for detailed instructions.

- **SS1:**

The configuration interface related to SS1 is [SS1](#). On your initial use of the SMG digital gateway,

you may adopt the default value of the configuration items on this interface.

Note: After configuring the SS1 interface, you shall restart the service to validate the settings. Refer to [3.12.18 Restart](#) for detailed instructions.

Step 10: Check the PSTN status.

After the configuration of signaling protocols, you can check the status of the PSTN trunks via 'Operation Info → PSTN Status'. Refer to [3.2.2 PSTN Status](#) for detailed introductions. When Time Slot 0 shows 'Frame Synchronized', the signaling time slot is in the state of 'Signaling Channel' and all the other channels are 'Idle', it indicates the PCM is well configured. If Time Slot 0 or the signaling time slot shows 'Faulty' or the other channels are in the state of 'Unavailable', there may be errors in the signaling protocol configurations and we suggest you return to Step 9 for check.

Step 11: Set routing rules for calls.

Note: For your easy understanding and manipulation, all examples given in this step do not involve registration.

Situation 1: IP → PSTN

Step 1: Configure the IP address of the remote SIP terminal which can establish conversations with the gateway so that the calls from other terminals will be ignored. Refer to 'SIP Settings → [SIP Trunk](#)' for detailed instructions. Fill in 'Remote IP' and 'Remote Port' with the IP address and port of the remote SIP terminal which will initiate calls to the gateway. You may use the default values for the other configuration items.

Example: Provided the IP address of the remote SIP terminal is 192.168.0.111 and the port is 5060. Add **SIP Trunk 0**; set **Remote IP** to **192.168.0.111** and **Remote Port** to **5060**.

Step 2: Add the IP address of the remote SIP terminal configured in Step 1 into the corresponding SIP trunk group. Refer to 'SIP Settings → [SIP Trunk Group](#)' for detailed instructions. Select the SIP trunk configured in Step 1 as 'SIP Trunks'. You may use the default values for the other configuration items.

Example: Add **SIP Trunk Group 0**. Check the checkbox before **0** for **SIP Trunks** and keep the default values for the other configuration items.

Step 3: Add PCM into the corresponding PCM Group. Refer to 'PCM Settings → [PCM Trunk Group](#)' for detailed instructions. Select the PCM used for call conversation as 'PCM'. You may use the default values for the other configuration items.

Example: Provided the PCM used for call conversation is PCM[1]. Add **PCM Trunk Group 0**, check the checkbox before **PCM[1]** and keep the default values for the other configuration items.

Step 4: Add routing rules. Refer to 'Route Settings → [IP→PSTN](#)' for detailed instructions. Select the SIP trunk group set in Step 2 as 'Call Initiator' and the PCM trunk group set in Step 3 as 'Call Destination'. You may use the default values for the other configuration items.

Example: Select **SIP Trunk Group[0]** as **Call Initiator** and **PCM Trunk Group[0]** as **Call Destination**. Keep the default values for the other configuration items.

Step 5: Initiate a call from the SIP terminal configured in Step 1 to the IP address and port of the SMG digital gateway. Thus you can establish a call conversation via PCM[1] with the PSTN terminal. (Note: The format used for calling an IP address via SIP trunk is as follows: username@IP address, in which, 'username' is a called party number which conforms to the number-receiving rule of the remote device.)

Example: Provided the IP address of the SMG digital gateway is 192.168.0.101 and the port is 5060. Provided 123 is a number which conforms to the number receiving rule of the remote device. Initiate a call from SIP terminal 0 to the IP address 192.168.0.101 (in the format: 123@192.168.0.101) and you can establish a call conversation via PCM[1] to

the number 123.

Situation 2: PSTN → IP

Step 1: Configure the called party numbers which are received from PSTN and will be processed by the gateway. Refer to 'Advanced Settings → [Number-receiving Rule](#)' for detailed instructions. Enter either a particular number or a string of 'x's to represent several random numbers. For example, 'xxx' denotes 3 random numbers. You may use the default value for 'Index'.

Example: Set **Index** to **99** and configure **Dial Rule** to **123**.

Step 2: Set the IP address of the SIP terminal to be called by the gateway. Refer to 'SIP Settings → [SIP Trunk](#)' for detailed instructions. Fill in 'Remote IP' and 'Remote Port' with the IP address and port of the SIP trunk. You may use the default values for the other configuration items.

Example: Provided the IP address of the SIP trunk to be called is 192.168.0.111 and the port is 5060. Add **SIP Trunk 0**; set **Remote IP** to **192.168.0.111** and **Remote Port** to **5060**.

Step 3: Add the IP address of the remote SIP terminal configured in Step 2 into the corresponding SIP trunk group. Refer to 'SIP Settings → [SIP Trunk Group](#)' for detailed instructions. Select the SIP trunk configured in Step 2 as 'SIP Trunks'. You may use the default values for the other configuration items.

Example: Add **SIP Trunk Group 0**. Check the checkbox before **0** for **SIP Trunks** and keep the default values for the other configuration items.

Step 4: Add PCM into the corresponding PCM Group. Refer to 'PCM Settings → [PCM Trunk Group](#)' for detailed instructions. Select the PCM used for call conversation as 'PCM'. You may use the default values for the other configuration items.

Example: Provided the PCM used for call conversation is PCM[1]. Add **PCM Trunk Group 0**, check the checkbox before **PCM[1]** and keep the default values for the other configuration items.

Step 5: Add routing rules. Refer to 'Route Settings → [PSTN→IP](#)' for detailed instructions. Select the PCM trunk group set in Step 4 as 'Call Initiator' and the SIP trunk group set in Step 3 as 'Call Destination'. You may use the default values for the other configuration items.

Example: Select **PCM Trunk Group[0]** as **Call Initiator** and **SIP Trunk Group[0]** as **Call Destination**. Keep the default values for the other configuration items.

Step 6: Once PCM[1] receives a call from PSTN and the called party number conforms to the number-receiving rules set in Step 1, it can establish a call conversation with the remote SIP terminal via the gateway.

Example: Once PCM[1] receives a call from PSTN with the called party number 123, it will route the call to SIP Trunk 0 of the gateway.

Special Instructions:

- The chassis of the SMG digital gateway must be grounded for safety reasons, according to standard industry requirements. A simple way is earthing with the third pin on the plug or the grounding studs on the machine. No or improper grounding may cause instability in operation as well as decrease in lightning resistance.
- As the device will gradually heat up while being used, please maintain good ventilation to prevent sudden failure, ensuring that the ventilation holes (see Figure 1-4) are never jammed.
- During runtime, if the alarm indicator lights up or flashes, it indicates that the device goes abnormal. If you cannot figure out and solve the problem by yourself, please contact our

technicians for help. Otherwise it may lead to a drop in performance or unexpected errors.

Chapter 3 WEB Configuration

3.1 System Login

Type the IP address into the browser and enter the login interface. See Figure 3-1.



Figure 3-1 Login Interface

The gateway only serves one user, whose original username and password are both 'admin'. You can change the username and the password via 'System Tools → Change Password' on the WEB interface. For detailed instructions, refer to [3.12.16 Change Password](#).

After login, you can see the main interface as below.



Figure 3-2 Main Interface

3.2 Operation Info

Operation Info includes five parts: **System Info**, **PSTN Status**, **SS7 Serve**, **Call Monitor** and **Call Count** showing the current running status of the gateway. See Figure 3-3.




Figure 3-3 Operation Info

3.2.1 System Info

System Info				
LAN 1				
MAC Address	00:00:E0:10:1C:C9			
IP Address	201.123.112.26	255.255.255.0		201.123.112.254
DNS Server	0.0.0.0			
Receive Packets	All:3145158	Error:0		Drop:0
Transmit Packets	All:8675865	Error:0		Drop:0
Current Speed	Receive:10.7 KB/s	Transmit:11.4 KB/s		
Work Mode	100Mb/s Full Duplex			
LAN 2				
MAC Address	00:00:E0:10:1C:CA			
IP Address	192.168.0.101	255.255.255.0		192.168.0.254
DNS Server	0.0.0.0			
Receive Packets	All:0	Error:0		Drop:0
Transmit Packets	All:0	Error:0		Drop:0
Current Speed	Receive:0 B/s	Transmit:0 B/s		
Work Mode	Unknown! Unknown			
Runtime	22h 0m 48s			
Operating Mode	ISDN(user)			
Current Version				
Serial Number	000000934(16)			
WEB	1.6.2_2015081416			
Gateway	1.6.2_2015081416			
Uboot	2.0.4_201411			
Kernel	#350 SMP Wed Aug 5 09:46:48 CST 2015			
Firmware	13			
Refresh				

Figure 3-4 System Info Interface

See Figure 3-4 for the system info interface. You can click **Refresh** to obtain the latest system information. The table below explains the items shown in Figure 3-4.

Item	Description														
MAC Address	MAC address of LAN 1 or LAN 2.														
IP Address	The three parameters from left to right are IP address, subnet mask and default gateway of LAN 1 or LAN 2.														
DNS Server	DNS server address of LAN 1 or LAN 2.														
Receive Packets	The amount of receive packets after the gateway's startup, including three categories: All, Error and Drop.														
Transmit Packets	The amount of transmit packets after the gateway's startup, including three categories: All, Error and Drop.														
Current Speed	The current speed of data receiving and transmitting.														
Work Mode	The work mode of the network, including five options: 10 Mbps Half Duplex, 10 Mbps Full Duplex, 100 Mbps Half Duplex, 100 Mbps Full Duplex and 1000 Mbps Full Duplex.														
Runtime	Time of the gateway keeping running normally after startup. This parameter updates every 2s.														
Operating Mode	The operating mode of the gateway includes:														
	<table><tr><th>Operating Mode</th><th>Description</th></tr><tr><td>Master Server</td><td>The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. If the dual gateway feature is enabled, the current gateway serves as the master server.</td></tr><tr><td>Slave Server</td><td>The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. This operating mode works only when the dual gateway feature is enabled and the current gateway serves as the slave server.</td></tr><tr><td>Client</td><td>The current gateway applies the SS7 protocol and is only used for voice transmission.</td></tr><tr><td>ISDN(User-side)</td><td>The current gateway is configured to be ISDN user-side..</td></tr><tr><td>ISDN(Network-side)</td><td>The current gateway is configured to be ISDN network-side.</td></tr><tr><td>SS1</td><td>The current gateway is configured to be SS1.</td></tr></table>	Operating Mode	Description	Master Server	The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. If the dual gateway feature is enabled, the current gateway serves as the master server.	Slave Server	The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. This operating mode works only when the dual gateway feature is enabled and the current gateway serves as the slave server.	Client	The current gateway applies the SS7 protocol and is only used for voice transmission.	ISDN(User-side)	The current gateway is configured to be ISDN user-side..	ISDN(Network-side)	The current gateway is configured to be ISDN network-side.	SS1	The current gateway is configured to be SS1.
	Operating Mode	Description													
	Master Server	The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. If the dual gateway feature is enabled, the current gateway serves as the master server.													
	Slave Server	The current gateway applies the SS7 protocol and is used for both signaling and voice transmission. This operating mode works only when the dual gateway feature is enabled and the current gateway serves as the slave server.													
	Client	The current gateway applies the SS7 protocol and is only used for voice transmission.													
	ISDN(User-side)	The current gateway is configured to be ISDN user-side..													
ISDN(Network-side)	The current gateway is configured to be ISDN network-side.														
SS1	The current gateway is configured to be SS1.														
Serial Number	Unique serial number of an SMG digital gateway.														
WEB	Current version of the WEB interface.														
Gateway	Current version of the gateway service.														
Uboot	Current version of Uboot.														
Kernel	Current version of the system kernel on the gateway.														
Firmware	Current version of the firmware on the gateway.														

3.2.2 PSTN Status




Figure 3-5 PSTN Status Interface for E1 Lines





















Figure 3-6 PSTN Status Interface for T1 Lines

See Figure 3-5 and Figure 3-6 for the PSTN status interface which shows the real-time status of each PCM on the gateway, including line synchronization, signaling link information and channel states.

Item	Description
Port	Serial number of the E1/T1 port on the device.
Time Slot No.	PCM time slot number in the port.
State	<p>Displays the channel state in real time. You can move the mouse onto the channel state icon for detailed information about the channel and the call, such as: call direction, calling party number and called party number.</p> <ul style="list-style-type: none"> For Time Slot 0, the channel state indicates the synchronization status of E1/T1.

	State	Color	Description
	Frame Sync		Frame synchronization normal. The synchronization status is 0x0.
	Faulty		<p>Configuration errors or hardware failure.</p> <p>You can move the mouse onto the icon for the hexadecimal value for synchronization status which consists of 16 bits and bit 0 is the lowest valid bit. If the bit value is equal to 0, it indicates that the synchronization status is normal; if the bit value is equal to 1, see below for details:</p> <p>bit0=1: basic frame synchronization loss</p> <p>bit1=1: duration of the basic frame synchronization loss exceeds 100ms</p> <p>bit2=1: CAS re-synchronization</p> <p>bit3=1: CRC re-synchronization</p> <p>bit4=1: remote alarm indication</p> <p>bit5=1: signal alarm indication</p> <p>bit6=1: all-ones alarm signal of time slot 16</p> <p>bit7=1: signal loss</p> <p>bit9=1: MF alarm from the remote end</p> <p>bit10=1: open circuit</p> <p>bit11=1: short circuit</p> <p>Other bits: reserved, all remain 0</p>
	<ul style="list-style-type: none"> For the signaling time slot, the channel states include: 		
	State	Color	Description
	Signaling		<p>For SS7, this state indicates 'SS7 in service'.</p> <p>For ISDN, this state indicates 'multiple frames established' or 'timer recovery'.</p> <p>For SS1, this state indicates 'time slot synchronization normal'.</p>
	Faulty		<p>Configuration errors or hardware failure.</p> <p>For SS7, this state indicates 'SS7 out of service', 'initial alignment', 'aligned ready', 'aligned not ready' or 'processor outage'.</p> <p>For ISDN, this state indicates 'TEI unassigned', 'assign awaiting TEI', 'establish awaiting TEI', 'TEI assigned', 'awaiting establishment' or 'awaiting release'.</p> <p>For SS1, this state indicates 'time slot synchronization abnormal'.</p>
	Unused		This state indicates the signaling time slot on this E1/T1 is not used.
	<ul style="list-style-type: none"> For the other channels, the channel states include: 		
	State	Icon	Description

	<i>Unusable</i>		The channel is unavailable.
	<i>Circuit Reset</i>		The circuit is being reset.
	<i>Idle</i>		The channel is available.
	<i>Local Block</i>		The channel is blocked by the local application program and cannot receive incoming calls.
	<i>Remote Block</i>		The channel is blocked by the specific circuit/circuit group blocking messages sent from the remote PBX and cannot make outgoing calls.
	<i>Both Block</i>		The channel is blocked by the local end so as not to receive incoming calls, meanwhile, it is blocked by the remote PBX so as not to make outgoing calls either.
	<i>Wait Answer</i>		The channel receives the ringback tone and is waiting for the called party to pick up the phone.
	<i>Ringing</i>		The channel is in the ringing state.
	<i>Talking</i>		The channel is in a conversation.
	<i>Pending</i>		The channel is in the pending state
	<i>Dialing</i>		The channel is dialing.
	<i>Wait Message</i>		The channel is waiting for the message from remote PBX.
Statistics	The total amount of the channels for the corresponding status.		

Note: The gateway provides the fuzzy search feature on this interface. After you click any characters on Figure 3-5, Figure 3-6, and press the 'F' button, the search box will emerge on the right top of this page. Then you can input the key characters and the gateway will locate the channel on which there is an ongoing call that conforms to the fuzzy search condition.

Take an example: As shown in Figure 3-7, after we input the character 333 to the search box, and click the **Search** button, the gateway does a fuzzy search and locates that the ongoing call whose CalledID contains the character 333 occurs on Channel 5.




Figure 3-7 Search Calls

Note: Click **Record** to start recording on the matched channel. If more than one channel match a condition, only the channel with the largest number among them will be recorded.

3.2.3 SS7 Server

Users can see the SS7 Server option in the menu only when the configuration item **Signaling Protocol** on the PCM settings interface is set to **SS7-TUP** or **SS7-ISUP**.




Figure 3-8 SS7 Server Info Interface

See Figure 3-8 for the SS7 server info interface. This interface contains 7 status bars (Status Bar 1~7 in the above figure) and a configuration region (Region 8 in the above figure). Below are the detailed introductions.

● Status Bar 1 & 2: Receive/transmit message list

The receive/transmit message lists display the received and sent messages respectively, used for gateway debugging. The display content in these lists can be set by the configuration items in Region 8.

● Configuration Region 8: Properties configuration for receive/transmit message list

The table below explains the items in Configuration Region 8.

Item	Description
Server IP	IP address of the SS7 server, this item can be configured on the SS7 interface.
Work Mode	Work mode of the SS7 server which includes three modes: Master Server, Slave Server and Client.
Display Sent Messages	If this item is ticked, the transmit message list will display the message sent to the remote end.
Display Received Messages	If this item is ticked, the receive message list will display the message received from the remote end.
Display DPC & OPC	If this item is ticked, the receive/transmit message list will display DPC and OPC.
Display SNT Messages	If this item is ticked, the receive/transmit message list will display the SNT messages.

Display SNM Messages	If this item is ticked, the receive/transmit message list will display the SNM messages.
Auto Translate	<p>If this item is ticked, the received/sent messages displayed on this interface will be translated automatically in the following format:</p> <p style="text-align: center;">Date Time Total number Signaling link number# SIO Content</p> <p>For the TUP messages, SIO is just 'TUP' (0x84), followed by the message content. It is usually in the following format:</p> <p style="text-align: center;">Title code CIC=PCM:TS Message body</p> <p>If this item is not ticked, the received/sent messages displayed on this interface will be hexadecimal raw data.</p>

Users can configure the display content of the receive/transmit message list via the checkbox before each configuration item. After modification, click **Save** to apply the configurations. The changes will be shown in the list in real time. Click **Download** and you can download the log information of the SS7 server.

● Status Bar 3: Linkset/signaling link information

This region displays the information about signaling links and linksets. The table below explains the information items in Status Bar 3.

Item	Description
Linkset No.	Linkset number.
Linkset Status	Working state of the linkset, including <i>In service</i> and <i>Out of service</i> . A signaling linkset will go into the state <i>In service</i> as long as one link in it is at the state of <i>In service</i> .
Link@Physical Address	Signaling link number and its physical position. For example, '0 @ IP[0]:PCM[0]' means the physical position of Link 0 in this gateway is the E1 with the local PCM numbered 0 on Client 0.
Network	Whether the signaling link is registered to the gateway, including two states: <i>Connected</i> and <i>Disconnected</i> (or no display). The signaling link can be used normally only in the state of <i>Connected</i> .
Sync	Basic frame synchronization (Time Slot 0), including two states: <i>Sync</i> and <i>Async</i> . The signaling link can be used only in the state of <i>Sync</i> .
Link Status	Working state of the signaling link, including <i>In service</i> and <i>Initial alignment</i> . You can refer to 'Status Bar 6: Link information' for detailed information about link status.
Hold Time	Duration since the last time the signaling link enters into the state of <i>In service</i> .
Position	Times of positioning that occurs on the signaling link since the program starts.
Send MSU	Total number of messages sent on the signaling link since the program starts.
Receive MSU	Total number of messages received on the signaling link after the program starts.
Switchover MSU	Total number of messages switched over on the signaling link since the program starts.

● Status Bar 4: Client information

This region displays the information about client IP address and connection state. The table below explains the information items in Status Bar 4.

Item	Description
------	-------------

Client	Client number.
IP Address	IP address of the client. You can click the link of the IP address to visit the WEB interface of the client.
Network	Whether the client has been successfully connected to the gateway, including two states: <i>Connected</i> and <i>Disconnected</i> (or no display).

● Status Bar 5: DPC Information

This region displays the information about DPC. The table below explains the information items in Status Bar 5.

Item	Description
DPC#	DPC number which starts from 0.
DPC Code	Destination point code which is usually allocated by the central office.
DPC Status	Indicates whether the route to this DPC is available, involving two states <i>Available</i> and <i>Unavailable</i> . The message can be sent to the DPC only when the route to this DPC is at the state of <i>Available</i> . The DPC will turn into the state of <i>Available</i> as long as one of the linksets reaching the DPC is at the state of <i>In Service</i> .
DPC Route Table	Route to the DPC, i.e. linkset number.

● Status Bar 6: Link information

This status bar displays the detailed information on the state of all signaling links, usually used for searching the cause of service interrupt on a signaling link.

Link#	STA	L2	POC	LSC	FSN	ERR	CHO
Link Number	Link States 0-6	Link Failure Causes (interrupt)	Processor Failures 0-3	Live Communication Server Service 0-1	Forward Sequence Number	spare	spare
	0: uploaded but not started	0: normal	0: normal	0: service is unavailable			
	1: service interrupt	1: BSNR illegal	1: the local end processor failure	1: service is available			
	2: initial positioning	2: FIBR illegal	2: the remote end processor failure				
	3: positioned/ready	3: T2 timeout	3: both ends processor failure				

	4: positioned/ not ready	4: T6 timeout, the remote end busy					
	5: service on	5: L3 sends a command to stop					
	6: processor failure	6: signaling error rate too high					
		7: during the course of initial positioning, fail to enter a normal position					
		8: Timer 1 timeout					
		9: positioned and ready, receive the interrupt signal of the remote end					
		10: positioned but not ready, receive the interrupt signal of the remote end					
		11: in the state of Service On, receive the interrupt signal of the remote end					
		12: in a processor failure, receive the interrupt signal of the remote end					

● Status Bar 7: Runtime Log

Runtime log records all MTP3 commands and error information that pops up during the operation. This status bar displays all the log records generated after the digital gateway starts.

3.2.4 Call Monitor

PCM No.	TS No.	Call Direction	Remote Address	Channel Status	CallerID	CalleeID	Start Time	Duration
0	1	PSTN->IP	201.123.112.206:5060		88861158	114	2015-08-18 15:22:00	00:14:06

Figure 3-9 Call Monitor Interface

See Figure 3-9 for the call monitor Interface. Here you can set a condition for call monitoring. For example, as shown in Figure 3-9, set the CalleeID 114 as the monitoring condition, and after you click the **Set** button, all the calls containing the CalleeID 114 will display in the Call Info list. The table below explains the items shown in Figure 3-9.

Item	Description
Monitored CallerID, Monitored CalleeID, Monitored Remote Address	Sets the condition for the call monitoring. You can set to monitor the calls by CallerID, CalleeID or remote address.
Monitoring LAN Port	Selects the LAN port which is used to monitor the calls.
PCM No.	The number of the PCM, which starts from 0.
TS No.	PCM time slot number in the port.
Call Direction	The direction of the monitored call, including two options: IP→ PSTN and PSTN→IP.
Remote Address	The remote address of the monitored call.
Channel Status	The status of the channel which the monitored call locates at.
CallerID	The CallerID of the monitored call.
CalleeID	The CalleeID of the monitored call.
Start Time	The start time of the monitored call.
Duration	The duration of the monitored call.

Click the icon in the channel status column, and you can monitor the call in real-time. If your computer is not installed with the monitoring plug-in, click the icon and you will see a prompt asking you to set the security level. Follow the instructions to configure the IE explorer: Open it and click 'Tools > Internet Options > Security Tab'; then click 'Custom Level' and enable 'Initialize and script ActiveX controls not marked as safe for scripting'. If there is a shadow showing under

the icon, such as , it means the monitoring goes successful. Click the icon again to cancel the monitoring.

Note: If a channel has been monitored from the very beginning, the monitoring, even if not yet cancelled, will terminate once the channel is removed from the monitor list.

3.2.5 Call Count

PSTN Call Statistics							
Trunk No.	Signaling Type	Current Number of IP→PSTN	Total Number of IP→PSTN	Connection Rate of IP→PSTN	Current Number of PSTN→IP	Total Number of PSTN→IP	Connection Rate of PSTN→IP
0	SS7-TUP	0	0	--	0	0	--
1	SS7-TUP	0	0	--	0	0	--
2	SS7-ISUP	0	0	--	0	0	--
3	SS7-ISUP	0	0	--	0	0	--
Total	---	0	0	--	0	6	--

SIP Call Statistics						
SIP Index	Current Number of IP→PSTN	Total Number of IP→PSTN	Connection Rate of IP→PSTN	Current Number of PSTN→IP	Total Number of PSTN→IP	Connection Rate of PSTN→IP
0	0	0	--	0	0	--

Statistics on IP→PSTN Release Cause								
Release Cause	Normal call clearing	Cancelled by calling party	User busy	No answer from user	Route failed	Resource unavailable	Unallocated number	Call rejected
Amount	0	0	0	0	0	0	0	0
Percentage	--	--	--	--	--	--	--	--

Statistics on PSTN→IP Release Cause								
Release Reason	Normal call clearing	Cancelled by calling party	User busy	No answer from user	Route failed	Resource unavailable	Call failed	Others
Number	0	0	0	0	0	0	0	0
Percentage	--	--	--	--	--	--	--	--

Figure 3-10 Call Count Interface

See Figure 3-10 for the call count Interface. The above list shows the detailed information about all the calls counted from the startup of the gateway service to the latest open or refresh of this interface. This interface includes three parts: PSTN Call Statistics, Statistics on PSTN Release Cause and Statistics on Sip Release Cause. You can click **Refresh** to obtain the latest call count information. The table below explains the items shown in Figure 3-10.

Item	Description
Trunk No.	The number of the PCM trunk, numbered from 0.
Signaling Type	The signaling protocol applied on the digital trunk, including: <i>ISDN User Side</i> , <i>ISDN Network Side</i> , <i>SS7-TUP</i> , <i>SS7-ISUP</i> , and <i>SS1</i> .
Current Number of IP→PSTN	The number of current calls from IP to PSTN.
Total Number of IP→PSTN	The total number of current calls from IP to PSTN.
Connection Rate of IP→PSTN	The percentage of successful IP→PSTN calls to total IP→PSTN calls.
Current Number of PSTN→IP	The number of current calls from PSTN to IP.
Total Number of PSTN→IP	The total number of current calls from PSTN to IP.
Connection Rate of PSTN→IP	The percentage of successful PSTN→IP calls to total PSTN→IP calls.
Total	Total number and connection rate of calls on all available tunks

SIP Index	The index of the SIP trunk.
Release Cause	Reason to release the call.
Normal call clearing	Total number of the calls which are normally cleared.
Cancelled by calling party	Total number of the calls which are cancelled by the calling party.
User busy	Total number of the calls which fail as the called party has been occupied and replies a busy message.
No answer from user	Total number of the calls which fail as the called party does not pick up the call in a long time or the calling party hangs up the call before the called party picks it up.
Routing failed	Total number of the calls which fail because no routing rules are matched.
Resource unavailable	Total number of the calls which fail because no voice channel is available.
Unallocated number	Total number of the calls which fail as the called party number is unallocated.
Call rejected	Total number of the calls which fail as the called party replies a rejection message.
Normal unspecified	Total number of the calls which fail as the called party number is normal but unspecified.
Call failed	Total number of the calls which fail as the called party number does not conform to the number-receiving rule or for relative reasons.
Others	Total number of the calls which fail due to other unknown reasons.
Percentage	The percentage of the calls with a release cause to total calls.

3.3 SIP Settings

SIP Settings includes five parts: **SIP**, **SIP Trunk**, **SIP Register**, **SIP Account**, **SIP Trunk Group** and **Media**. See Figure 3-11. **SIP** is used to configure the general SIP parameters; **SIP Trunk** is used to set the basic and register information of the SIP trunk; **SIP Register** is used for the registration of SIP; **SIP Account** is used for registering SIP accounts to the SIP server; **SIP Trunk Group** is to manage SIP trunks by group; and **Media** is to set the RTP port and the payload type.




Figure 3-11 SIP Settings

3.3.1 SIP Settings

SIP Settings	
SIP Address of WAN	LAN 1: 201.123.112.26
Auto Change Default Gateway	<input type="checkbox"/> Enable
SIP Signaling Port	5060
Send 183 Message	<input checked="" type="checkbox"/> Enable
Obtain CallerID from	Username of From Field
Obtain CalleeID from	Request Field
Obtain Redirecting Number/Original CalleeID from Diversion Field	<input type="checkbox"/> Enable
NAT Traversal	<input checked="" type="checkbox"/> Enable
Traversal Type	Port Mapping
LAN1 Mapping Address	5.5.5.5
LAN2 Mapping Address	6.6.6.6
SIP Transport Protocol	UDP
SIP Encryption	<input checked="" type="checkbox"/> Enable
Encryption Criterion	VOS1.1
Key	
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
DSCP	<input checked="" type="checkbox"/> Enable
Voice Media	46
Signal Control	26
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Maximum Wait Answer Time (s)	60
Maximum Wait RTP Time (s)	0
Maximum Wait PSTN Resource Time(ms)	5000

Figure 3-12 SIP Settings Interface


See Figure 3-12 for the SIP settings interface where you can configure the general SIP parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-12.

Item	Description
SIP Address of WAN	IP address of WAN for SIP signaling, using LAN 1 by default.
Auto Change Default Gateway	The SIP address of WAN will automatically shift to another LAN if the default one is unavailable. By default, the feature is disabled.
SIP Port	Monitoring port of SIP signaling. Range of value: 1024~65535, with the default value of 5060.
183 Message Behavior	Sets whether to send the 183 message instead of 180 to respond to the ringing tone when the SIP end serves as the called party. By default this feature is enabled.
Obtain CallerID from	There are two optional ways to obtain the calling party number: from <i>Username of "From" Field</i> or from <i>Displayname of "From" Field</i> . The default value is from <i>Username of "From" Field</i> .
Obtain CalleeID from	There are two optional ways to obtain the called party number: from <i>"To" Field</i> or from <i>"Request" Field</i> . The default value is from <i>"Request" Field</i> .
Obtain Redirecting Number/Original CalleeID from Diversion Field	Sets whether to enable the feature of obtaining the Redirecting Number/Original CalleeID from Diversion Field. By default, the feature is disabled.
NAT Traversal, Traversal Type	Sets whether to enable the feature of NAT Traversal. By default, the feature is disabled. There is only one optional traversal type: <i>Port Mapping</i> .
LAN1 Mapping Address, LAN2 Mapping Address	The mapping address of the LAN1 and LAN2 in case the NAT traversal is enabled. If the port mapping is selected as the traversal type, you are required to set the mapping address and port on the router and fill in the corresponding information here as well.
SIP Transport Protocol	There are two modes <i>UDP</i> and <i>TCP</i> available for running the SIP protocol. The default value is <i>UDP</i> .
SIP Encryption	Once this feature is enabled, you can encrypt the SIP signal following selecting an encryption criterion and setting a key. By default it is <i>disabled</i> .
Encryption Criterion	The criterion used to encrypt the SIP signal. At present only VOS1.1 is supported.
Key	The key to encrypt the SIP signal.
RTP Encryption	Once this feature is enabled, you can encrypt the RTP package. By default it is <i>disabled</i> .
RTP Self-adaption	When this feature is enabled, the RTP reception address or port carried by the signaling message from the remote end, if not consistent with the actual state, will be updated to the actual RTP reception address or port. By default, this feature is <i>disabled</i> .
UDP Header Checksum	When this feature is enabled, the gateway will automatically calculate the check sum of the UDP header during RTP transmission.

Rport	When this feature is enabled, a corresponding Rport field will be added to the Via message of SIP. By default, it is <i>disabled</i> .
DSCP	Sets whether to enable the DSCP differentiated services code point. By default, it is <i>disabled</i> .
Voice Media	Sets the priority of the voice media for DSCP. The voice media with a bigger value has a higher priority. The value range is 0~63, with the default value of 46.
Signal Control	Sets the priority of the signal control for DSCP. The signal control with a bigger value has a higher priority. The value range is 0~63, with the default value of 26.
Calls from SIP Trunk Address only	Once this feature is enabled, the gateway will only accept the calls from the IP addresses set in SIP Settings → SIP Trunk. By default, it is <i>disabled</i> .
Switch Signal Port if SIP Registration Failed	If the SIP registration fails, the SIP signaling port N will switch to N+1 for a new registration. It will continue until the registration succeed.
Working Period, Period	The work period for the gateway, You can specify a certain period for the gateway to make calls. By default, the gateway is allowed to make calls any time in the day (24 Hours).
Maximum Wait Answer Time	Sets the maximum time for the SIP channel to wait for the answer from the called party of the outgoing call it initiates. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 60, calculated by s.
Maximum Wait RTP Time	Sets the maximum time for the SIP channel to wait for the RTP packet. If no RTP packet is received within the specified time period, the channel will enter the pending state automatically and release the call. The default value is 0, calculated by s.
Maximum Wait PSTN Resource Time	Sets the maximum wait time to search the idle PSTN resource for the incoming call from IP. The call will be failed if no channel is found during this time. The value range is 0~10000, calculated by ms, with the default value of 5000.

3.3.2 SIP Trunk



Check	Index	Remote Address	Remote Port	WAN Option	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List	Working Period	Modify
<input type="checkbox"/>	0	201.123.112.66	5069	NET 1	UDP	128	128	G711A,G711U,G729,G722,ILBC	24 Hours	
<input type="checkbox"/>	1	201.123.112.66	5063	NET 1	UDP	128	128	G711A,G711U,G729,G722,ILBC	24 Hours	

Check All Uncheck All Inverse Delete Clear All Add New

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-13 SIP Trunk Settings Interface

See Figure 3-13 for the SIP trunk settings interface. A new SIP trunk can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-14 for the SIP trunk adding interface.

SIP Trunk

Index:

Remote Address:

Remote Port:

WAN Option:

Transport Protocol:

Outgoing Voice Resource:

Incoming Voice Resource:

Working Period: ☒ 24 Hours

Check	Codec	Check	Codec
<input checked="" type="checkbox"/> 1	<input type="text" value="G711A"/>	<input checked="" type="checkbox"/> 5	<input type="text" value="iLBC"/>
<input checked="" type="checkbox"/> 2	<input type="text" value="G711U"/>		
<input checked="" type="checkbox"/> 3	<input type="text" value="G729"/>		
<input checked="" type="checkbox"/> 4	<input type="text" value="G722"/>		

Figure 3-14 Add New SIP Trunk

The table below explains the items shown in Figure 3-14.

Item	Description
Index	The unique index of each SIP trunk.
Remote Address	Address of the SIP trunk, i.e. the IP address or domain name of the remote SIP terminal which will establish call conversation with the gateway.
Remote Port	Port of the SIP trunk.
WAN Option	Select the network port used for WAN. The default setting is NET 1.
Transport Protocol	SIP transport protocol, providing two modes <i>UDP</i> and <i>TCP</i> . The default value is <i>UDP</i> .
Outgoing Voice Resource	Maximum number of voice channels for the outgoing calls allocated by the SIP trunk to the gateway.
Incoming Voice Resource	Maximum number of voice channels for the Incoming calls allocated by the SIP trunk to the gateway.

Working Period, Period	The work period for the gateway, You can specify a certain period for the gateway to make calls. By default, the gateway is allowed to make calls any time in the day (24 Hours).						
CODEC	<p>Supported CODECs and their corresponding priorities for the SIP trunk to establish a call conversation. The table below explains the sub-items:</p> <table border="1"> <thead> <tr> <th>Sub-item</th><th>Description</th></tr> </thead> <tbody> <tr> <td><i>Priority</i></td><td>Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.</td></tr> <tr> <td><i>CODEC</i></td><td>Seven optional CODECs are supported: G711A, G711U, G729AB, G723, G722, AMR and iLBC.</td></tr> </tbody> </table> <p>See 3.3.6 Media Settings for the detailed parameters for each CODEC.</p> <p>The default CODEC for the SIP trunk is the same as that set in 3.3.6 Media Settings.</p>	Sub-item	Description	<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.	<i>CODEC</i>	Seven optional CODECs are supported: G711A, G711U, G729AB, G723, G722, AMR and iLBC.
Sub-item	Description						
<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.						
<i>CODEC</i>	Seven optional CODECs are supported: G711A, G711U, G729AB, G723, G722, AMR and iLBC.						

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-13 to modify a SIP trunk. See Figure 3-15 for the SIP trunk modification interface. The configuration items on this interface are the same as those on the **Add New SIP Trunk** interface.

SIP Trunk

Index:

Remote Address:

Remote Port:

WAN Option:

NET 1

Transport Protocol:

UDP

Outgoing Voice Resource:

Incoming Voice Resource:

Working Period:

☒ 24 Hours

Check	Codec	Check	Codec
<input checked="" type="checkbox"/> 1	<div style="border: 1px solid #ccc; padding: 2px 5px;">G711A</div>	<input checked="" type="checkbox"/> 5	<div style="border: 1px solid #ccc; padding: 2px 5px;">iLBC</div>
<input checked="" type="checkbox"/> 2	<div style="border: 1px solid #ccc; padding: 2px 5px;">G711U</div>		
<input checked="" type="checkbox"/> 3	<div style="border: 1px solid #ccc; padding: 2px 5px;">G729</div>		
<input checked="" type="checkbox"/> 4	<div style="border: 1px solid #ccc; padding: 2px 5px;">G722</div>		

Save

Close

Figure 3-15 Modify SIP Trunk

To delete a SIP trunk, check the checkbox before the corresponding index in Figure 3-13 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP trunks at a time, click the **Clear All** button in Figure 3-13.

3.3.3 SIP Register




Figure 3-16 SIP Register Configuration Interface

See Figure 3-16 for the SIP Register Configuration interface. By default, there is no SIP register available on the gateway. Click **Add New** to add them manually. See Figure 3-17.

The image shows a web-based configuration interface titled "SIP Register". It contains several input fields and dropdown menus for configuring a SIP register. The fields are arranged vertically, each with a label and a corresponding input area. At the bottom, there are two buttons: "Save" and "Close".

Field Label	Value / Option
Index:	0
SIP Trunk No.:	0 (dropdown)
Username:	
Password:	
Register Address:	
Register Port:	5060
Domain Name:	
Register Expires (s):	3600
IMS Network:	Yes (dropdown)
Externally Bound Address:	
Externally Bound Port:	
Authentication Username:	

Figure 3-17 Add SIP Register Interface

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each SIP register.
SIP Trunk No.	The number of the SIP trunk which registers to the SIP server.
Username	When the gateway initiates a call to SIP, this item corresponds to the username of SIP; when the gateway initiates a call to PSTN, this item corresponds to the displayed CallerID.
Password	Registration password of the gateway. To register the gateway to the SIP server, both configuration items Username and Password should be filled in.
Register Address	Address of the SIP server to which the SIP trunk is registered.

Register Port	The signaling port of the SIP trunk.
Domain Name	Domain name of the gateway used for SIP registry.
Register Expires	Validity period of the SIP registry. Once the registry is overdue, the gateway should be registered again. Range of value: 10~3600, calculated by s, with the default value of 3600.
IMS Network	Once this feature is enabled, the gateway will send signaling messages to the corresponding externally bound address and port when it registers to the server. Only when this feature is <i>enabled</i> will these items Externally Bound Address , Externally Bound Port and Authentication Username be shown.
Externally Bound Address	Externally bound IP address for registration.
Externally Bound Port	Externally bound port for registration.
Authentication Username	Authentication username for registration.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.


Check	Index	SIP Trunk No.	Username	Register Address	Register Port	Domain Name	Register Expires (s)	Register Status	IMS Network	Externally Bound Address
<input type="checkbox"/>	0	0	100	201.123.115.26	5060	--	3600	Failed	No	--

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-18 SIP Register Information List

Click **Modify** in Figure 3-18 to modify a SIP register. The configuration items on the SIP Register Modification Interface are the same as those on the **Add New SIP Register** interface.



The interface is titled "SIP Register" and contains the following fields and buttons:

- Index:** Text input field with value "0".
- SIP Trunk No.:** Dropdown menu with value "0".
- Username:** Text input field with value "100".
- Password:** Text input field with masked characters "•••".
- Register Address:** Text input field with value "201.123.115.26".
- Register Port:** Text input field with value "5060".
- Domain Name:** Text input field.
- Register Expires (s):** Text input field with value "3600".
- IMS Network:** Dropdown menu with value "Yes".
- Externally Bound Address:** Text input field.
- Externally Bound Port:** Text input field.
- Authentication Username:** Text input field.
- Buttons:** "Save" and "Close" buttons at the bottom.

Figure 3-19 SIP Register Modification Interface

To delete a SIP register, check the checkbox before the corresponding index in Figure 3-18 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP registers at a time, click the **Clear All** button in Figure 3-18.

3.3.4 SIP Account


SIP Account								
Check	Index	SIP Trunk No.	Username	Authentication Username	Register Expires (s)	Register Status	Description	Modify
<input type="checkbox"/>	0	0	111		3600	Failed	default	
<div><div><div>Check All</div><div>Uncheck All</div><div>Inverse</div><div>Delete</div><div>Clear All</div></div><div>Add New</div></div>								
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total								

Figure 3-20 SIP Account Settings Interface

See Figure 3-20 for the SIP account settings interface. A new SIP account can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-21 for the

SIP account adding interface.

Figure 3-21 Add New SIP Account


The table below explains the items shown in above figures.

Item	Description
Index	The unique index of each SIP account.
SIP Trunk No.	The number of the SIP trunk to which the SIP account is registered.
Username	The registration username of the SIP account. Once the SIP account is successfully registered, the SIP server can initiate calls to the gateway via Username .
Password	The registration password of the SIP account. To register the SIP account to the SIP trunk, both configuration items Username and Password should be filled in.
Register Expires	The validity period of the SIP account registry. Once the registry is overdue, the SIP account should be registered again. Range of value: 10~3600, calculated by s, with the default value of 3600.
Register Status	The registration status of the SIP account. It is either <i>Registered</i> or <i>Failed</i> .
Authentication Username	Authentication username of a port, used to register the port to the SIP server when IMS network is enabled. Note: This item appears only when IMS Network is enabled on the SIP trunk corresponding to this SIP account.
Description	More information about each SIP account.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-20 to modify a SIP account. See Figure 3-22 for the SIP account modification interface. The configuration items on this interface are the same as those on the **Add**

New SIP Account interface.



The image shows a 'SIP Account' configuration window. It contains several input fields: 'Index' with value 0, 'SIP Trunk No.' with value 0 and a dropdown arrow, 'Username' with value 111, 'Password' with masked characters (dots), 'Register Expires (s)' with value 3600, 'Authentication Username' (empty), and 'Description' with value 'default'. At the bottom are 'Save' and 'Close' buttons.

Figure 3-22 Modify SIP Account

To delete a SIP account, check the checkbox before the corresponding index in Figure 3-20 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP accounts at a time, click the **Clear All** button in Figure 3-20.

3.3.5 SIP Trunk Group


SIP Trunk Group					
Check	Index	SIP Trunks	SIP Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>					
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page <input type="text" value="1"/> 1 Pages Total					

Figure 3-23 SIP Trunk Group Settings Interface

See Figure 3-23 for SIP trunk group settings interface. A new SIP trunk group can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-24 for the SIP trunk group adding interface.

The screenshot shows a web-based configuration interface titled "Add New". It contains the following elements:

- Index:** A dropdown menu with the value "1" selected.
- Description:** A text input field containing the word "default".
- SIP Trunk Select Mode:** A dropdown menu with the value "Increase" selected.
- SIP Trunks:** A section with a "Check All" checkbox and two individual checkboxes labeled "0" and "1".
- Buttons:** "Save" and "Cancel" buttons at the bottom.

Figure 3-24 Add New SIP Trunk Group

The table below explains the items shown in Figure 3-24.

Item	Description										
Index	The unique index of each SIP trunk group, which is mainly used in the configuration of routing rules and number manipulation rules to correspond to SIP trunk groups.										
Description	More information about each SIP trunk group.										
SIP Trunk Select Mode	<p>When the SIP trunk group receives a call, it will choose a SIP trunk based on the select mode set by this configuration item to ring. The optional values and their corresponding meanings are described in the table below.</p> <table border="1"> <thead> <tr> <th>Option</th><th>Description</th></tr> </thead> <tbody> <tr> <td><i>Increase</i></td><td>Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.</td></tr> <tr> <td><i>Decrease</i></td><td>Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.</td></tr> <tr> <td><i>Cyclic Increase</i></td><td>Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.</td></tr> <tr> <td><i>Cyclic Decrease</i></td><td>Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.</td></tr> </tbody> </table>	Option	Description	<i>Increase</i>	Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.	<i>Decrease</i>	Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.	<i>Cyclic Increase</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.	<i>Cyclic Decrease</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.
Option	Description										
<i>Increase</i>	Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from the minimum.										
<i>Decrease</i>	Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from the maximum.										
<i>Cyclic Increase</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the ascending order of the SIP trunk number, starting from SIP Trunk N+1.										
<i>Cyclic Decrease</i>	Provided SIP Trunk N is the available SIP trunk found last time. Search for an idle SIP trunk in the descending order of the SIP trunk number, starting from SIP Trunk N-1.										
SIP Trunks	The SIP trunks in the SIP trunk group. If the checkbox before a SIP trunk is grey, it indicates that the SIP trunk has been occupied. The ticked SIP trunks herein will be displayed in the column 'SIP Trunks' in Figure 3-23.										

After configuration, click **Save** to save the settings into the gateway or click **Cancel** to cancel the settings.

Click **Modify** in Figure 3-23 to modify a SIP trunk group. See Figure 3-25 for the SIP trunk group modification interface. The configuration items on this interface are the same as those on the **Add New SIP Trunk Group** interface.




Figure 3-25 Modify SIP Trunk Group

To delete a SIP trunk group, check the checkbox before the corresponding index in Figure 3-23 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all SIP trunk groups at a time, click the **Clear All** button in Figure 3-23.

3.3.6 Media Settings

Media Parameters

DTMF Transmit Mode

RFC2833 ▼

RFC2833 Payload

101

RTP Port Range

6000,10000

Silence Suppression

Disable ▼

Noise Reduction

Enable ▼

JitterMode

Static Mode ▼

JitterBuffer(ms)

100

JitterUnderrunLead(ms)

100

JitterOverrunLead(ms)

50

Voice Gain Output from IP(dB)

0

CODEC Setting

Priority	CODEC	Packing Time(ms)	Bit Rate (kbps)
1	G711A ▼	20 ▼	64 ▼
2	G711U ▼	20 ▼	64 ▼
3	G729 ▼	20 ▼	8 ▼
4	G723 ▼	30 ▼	6.3 ▼
5	G722 ▼	30 ▼	64 ▼
6	AMR ▼	20 ▼	12.20 ▼
7	iLBC ▼	20 ▼	15.2 ▼

Save

Reset

Figure 3-26 Media Settings Interface

See Figure 3-26 for the media settings interface where you can configure the RTP port and payload type depending on your requirements. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-26.

Item	Description
DTMF Transmit Mode	Sets the mode for the IP channel to send DTMF signals. The optional values are <i>RFC2833</i> , <i>In-band</i> and <i>Signaling</i> , with the default value of <i>RFC2833</i> .
RFC2833 Payload	Payload of the RFC2833 formatted DTMF signals on the IP channel. Range of value: 90~127, with the default value of 101.

RTP Port Range	Supported RTP port range for the IP end to establish a call conversation, with the lower limit of 2000 and the upper limit of 60000 and the difference between larger than 512. The default value is <i>6000-10000</i> .				
Silence Suppression	Sets whether to send comfort noise packets to replace RTP packets or never to send RTP packets to reduce the bandwidth usage when there is no voice signal throughout an IP conversation. The optional values are <i>Enable</i> and <i>Disable</i> , with the default value of <i>Disable</i> . Note: When G723 is selected as CODEC, this configuration setting will turn to Enable automatically.				
Noise Reduction	Once this feature is enabled, the volume of the noise accompanied with the line will be reduced automatically. The default setting is <i>Enable</i> .				
JitterMode	Sets the working mode of JitterBuffer. The optional values are <i>Static Mode</i> and <i>Adaptive Mode</i> , with the default value of <i>Static Mode</i> .				
JitterBuffer	Acceptable jitter for data packets transmission over IP, which indicates the buffering capacity. A larger JitterBuffer means a higher jitter processing capability but as well as an increased voice delay, while a smaller JitterBuffer means a lower jitter processing capability but as well as a decreased voice delay. Range of value: 0~280, calculated by ms, with the default value of 100.				
JitterUnderrunLead	Sets the initial delay applied to received packets upon accepting packets later than the expected value set in JitterBuffer Item. Range of value: 0~280, calculated by ms, with the default value of 100, Note: Only when JitterMode is to <i>Static Mode</i> will this item be shown.				
JitterOverrunLead	Sets the beforehand time inserted if receiving packets is ahead of time (the time of receiving is earlier than 300 minus the value set in JitterBuffer). Range of value: 0~280, calculated by ms, with the default value of 50, Note: Only when JitterMode is to <i>Static Mode</i> will this item be shown.				
JitterMin	Sets the minimum delay that can be set by the adaptive jitter function. It can not be larger than the value set in JitterBuffer. Range of value: 0~280, calculated by ms, with the default value of 80. Note: Only when JitterMode is to <i>Adaptive Mode</i> will this item be shown.				
JitterDecreaseRatio	Sets the rate of the delay that can be reduced under the adaptive mode. It defines the maximum percentage of silence that can be removed if reducing the delay. Range of value: 0~100, with the default value of 50, Note: Only when JitterMode is to <i>Adaptive Mode</i> will this item be shown.				
JitterIncreaseMax	Sets the maximum delay can be increased during one silence period. Range of value: 0~280, calculated by ms, with the default value of 30, Note: Only when JitterMode is to <i>Adaptive Mode</i> will this item be shown.				
Voice Gain Output from IP	Adjusts the voice gain of call from IP to the remote end. The value must be a multiple of 3. Range of value: -24~24, calculated by dB, with the default value of 0.				
CODEC Setting	Sets CODECs for the IP end to establish a call conversation. The table below explains the sub-items: <table border="1" data-bbox="478 1948 1372 1993"> <thead> <tr> <th>Sub-item</th><th>Description</th></tr> </thead> <tbody> <tr> <td> </td><td> </td></tr> </tbody> </table>	Sub-item	Description		
Sub-item	Description				

<i>Priority</i>	Priority for choosing the CODEC in an SIP conversation. The smaller the value is, the higher the priority will be.
<i>CODEC</i>	Seven optional CODECs are supported: <i>G711A</i> , <i>G711U</i> , <i>G729AB</i> , <i>G723</i> , <i>G722</i> , <i>AMR</i> and <i>iLBC</i> .
<i>Packing Time</i>	Time interval for packing an RTP packet, calculated by ms.
<i>Bit Rate</i>	The number of thousand bits (excluding the packet header) that are conveyed per second.

By default, all of the seven CODECs are supported and ordered *G711A*, *G711U*, *G729AB*, *G723*, *G722*, *AMR* and *iLBC* by priority from high to low. The CODECs set here will be the default CODEC for the new added SIP trunks.

The packing time and bit rate supported by different CODECs are listed in the table below. Those values in bold face are the default values.

COEDC	Packing Time (ms)	Bit Rate (kbps)
<i>G711A</i>	5 / 10 / 20 / 30 / 40 / 50 / 60	64
<i>G711U</i>	5 / 10 / 20 / 30 / 40 / 50 / 60	64
<i>G729AB</i>	20	8
<i>G723</i>	30 / 60 / 90	5.3 / 6.3
<i>G722</i>	5 / 10 / 20 / 30 / 40	64
<i>AMR</i>	20 / 40 / 60 / 80 / 100	4.75 / 5.15 / 5.90 / 6.70 / 7.40 / 7.95 / 10.20 / 12.20
<i>iLBC</i>	20 / 40	15.2
	30	13.3
	60	13.3 / 15.2

3.4 PCM Settings

PCM Settings includes seven parts: **PSTN**, **Circuit Maintenance**, **PCM**, **PCM Trunk**, **PCM Trunk Group**, **Number-Receiving Rule**, and **Reception Timeout**. See Figure 3-27.




Figure 3-27 PCM Settings

3.4.1 PSTN

The image shows a 'PSTN Configuration' window with the following settings:

- Interface: E1 (dropdown)
- Encoding Format: A-law (dropdown)
- Echo Canceller: ☒ Enable
- Ringback Tone Provided by E1: ☐ Enable
- Ringback Tone Provided by IP: ☐ Enable
- Ringback Tone Volume(dB): -25 (text input)
- Voice Gain Output from PSTN(dB): 0 (text input)
- Hot Back-up for E1: ☒ Enable
- Gateway IP for Hot Back-up: (empty text input)
- E1 Incoming CalleeID Real-time Change: ☒ Enable
- Number Change Server Address: (empty text input)
- Number Change Server Port: (empty text input)
- Limited Length of E1 Outgoing CalleeID: 0 (text input)

At the bottom are 'Save' and 'Reset' buttons.

Figure 3-28 PSTN Settings Interface

See Figure 3-28 for the PSTN Settings interface. The table below explains the items shown in the above figure.

Item	Description
Interface	Actual type of the line connected with the E1/T1 interface on the gateway. Currently, only E1/T1 is supported.
Encoding Format	Sets the voice data encoding format for the voice channels on the digital trunk. The optional values are <i>A-law</i> and <i>u-law</i> , with the default value of <i>A-law</i> .
Echo Canceller	Sets whether to enable the echo cancellation feature for call conversations over the digital trunk. By default, this feature is enabled and the effect can reach 128ms.
Ringback Tone Provided by E1	Sets whether to enable the E1 end to provide the ringback tone, with the default value of <i>disable</i> .
Ringback Tone Provided by IP	Sets whether to enable the IP end to provide the ringback tone, with the default value of <i>disable</i> .
Ringback Tone Volume	Sets the volume of the ringback tone. Range of value: -35~-2, calculated by dB, with the default value of -25.

Voice Gain Output from PSTN	Adjusts the voice gain of call from PSTN to the remote end. The value must be a multiple of 3. Range of value: -24~24, calculated by dB, with the default value of 0.
Hot Back-up for E1	Sets whether to enable the feature of hot back-up for E1, with the default value of <i>disable</i> .
Gateway IP for Hot Back-up	Set the IP of the gateway for the hot back-up for E1.
E1 Incoming CalleeID Real-time Change	Once this feature is enabled, the gateway will send the CalleeID to the number change server and continue the SIP call progress using the changed number when it receives E1 calls. By default, it is <i>disabled</i> .
Number Change Server Address	The IP address of the server to change the CalleeID.
Number Change Server Port	The port of the server to change the CalleeID.
Limited Length of E1 Outgoing CalleeID	Limits the CalleeID length of the outgoing calls from PSTN side. The calleeID will be divided into two parts if its length is greater than the value set in this item. Range of value: 0~50. The default value is 0, not limited.

After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions.

3.4.2 Circuit Maintenance

PCM Maintenance																																
PCM No.	0								1								2								3							
PCM Status																																
Check	<input type="checkbox"/>								<input type="checkbox"/>								<input type="checkbox"/>								<input type="checkbox"/>							
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Block"/> <input type="button" value="Unblock"/> <input type="button" value="Physical Connect"/> <input type="button" value="Physical Disconnect"/>																																
PCM LoopBack Config																																
PCM No.	0								1								2								3							
PCM LoopBack Status																																
Check	<input type="checkbox"/>								<input type="checkbox"/>								<input type="checkbox"/>								<input type="checkbox"/>							
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Local LoopBack"/> <input type="button" value="Remote LoopBack"/> <input type="button" value="UnLoopBack"/>																																
Port 1																																
Channel No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Status																																
Check	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Block"/> <input type="button" value="Unblock"/>																																
Port 2																																
Channel No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Status																																
Check	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Block"/> <input type="button" value="Unblock"/>																																
Port 3																																
Channel No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Status																																
Check	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Block"/> <input type="button" value="Unblock"/>																																
Port 4																																
Channel No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Status																																
Check	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Block"/> <input type="button" value="Unblock"/>																																

Figure 3-29 Circuit Maintenance Interface

See Figure 3-29 for the Circuit Maintenance interface. You can block, unblock, physical connect or disconnect PCMs, ports and channels on this interface. You can set the loopback feature of trunks for diagnoses or debugging. **Local LoopBack** means the transmitted data loop back from the LIU transmitter to the LIU receiver; **Remote LoopBack** means the transmitted data loop back to the LIU transmitter after being decoded in the LIU receiver. **UnLoopBack** is used to disable the features of local loopback and remote loopback.

Check All means to select all available items for the current port; **Uncheck All** means to cancel all selections for the current port; **Inverse** means to uncheck the selected items and check the unselected.

3.4.3 PCM

PCM Settings								
PCM No.	Signaling Protocol	Clock	Signaling Time Slot	Signaling Link Type	Connection Line	Incoming Call Start TS,Amount	CRC-4	Modify
0	SS7-ISUP	Line-synchronization	16	Signaling	Twisted Pair Cable	--	Enable	
1	SS7-ISUP	Slave	16	Voice	Twisted Pair Cable	--	Enable	
2	SS7-ISUP	Slave	16	Voice	Twisted Pair Cable	--	Enable	
3	SS7-ISUP	Slave	16	Voice	Twisted Pair Cable	--	Enable	

Figure 3-30 PCM Settings Interface

See Figure 3-30 for the PCM settings interface. The above list shows the detailed information and configurations of each PCM. The table below explains the items shown in the above figure.

Item	Description
PCM No.	The number of the PCM, numbered from 0. This item is not configurable.
Signaling Protocol	<p>The signaling protocol applied on the digital trunk. It includes <i>ISDN User Side</i>, <i>ISDN Network Side</i>, <i>SS7-TUP</i>, <i>SS7-ISUP</i>, and <i>SS1</i> in E1, and only includes <i>ISDN User Side</i>, <i>ISDN Network Side</i> in T1.</p> <p>Note: 1, Changing the interface type from E1 to T1 will forbid those non-ISDN signaling modes in E1. And in such case, the gateway will by default set this item to <i>ISDN User Side</i>.</p> <p>2, For SMG3008, a single gateway can be configured with two different signaling modes simultaneously.</p> <p>3, For SMG3016, a single gateway can be configured with three different signaling modes simultaneously.</p>
Clock	The clock mode for the digital trunk, including <i>Line-synchronization</i> , <i>Free-run</i> and <i>Slave</i> .
Signaling Time Slot	Sets the time slot used for signaling transmission on the digital trunk. If the configuration item Signaling Protocol is set to <i>ISDN</i> and <i>SS1</i> , the signaling time slot is Time Slot 16 in E1 or Time Slot 24 in T1 (<i>SS1</i> not supported in T1 by far), which cannot be modified. For <i>SS7</i> signaling, up to 4 signaling time slots can be set.
Signaling Link Type	Indicates whether the PCM is used as a signaling link or a voice link. If no time slot is used to transmit signaling, the PCM is a voice link.
Connection Line	Physical connection line type.
Incoming Call Start TS, Amount	Sets a certain amount of channels which starts from a certain TS to process the incoming calls and others on the PCM to process outgoing calls. This is valid only when the configuration item Signaling Protocol is set to <i>SS1</i> .
CRC-4	Sets whether to enable the CRC-4 verification feature. By default, this feature is Enabled.

Click **Modify** in Figure 3-30 to modify a PCM. See Figure 3-31 for the PCM modification interface. Most configuration items on this interface are the same as those on the **PCM Settings** interface.




Figure 3-31 Modify PCM

The table below explains the other configuration items on the PCM modification interface.

Item	Description
Use 'Signaling Time Slot' for Signaling	If this item is checked, it indicates that the signaling time slot configured in Signaling Time Slot is used for signaling transmission. You can see this item only when the configuration item Signaling Protocol is set to SS7-TUP or SS7-ISUP .
Apply to All PCMs	Check this item to apply the above settings (excluding Clock) to all PCMs.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

3.4.4 PCM Trunk




Figure 3-32 PCM Trunk Configuration Interface

See Figure 3-32 for the PCM Trunk Configuration interface. By default, there is no PCM trunk available on the gateway. Click **Add New** or **Batch Add** to add them manually. See Figure 3-33, Figure 3-34.

PCM Trunk

Index:

PCM NO.:


Including Ts: ☐ Check All

<input type="checkbox"/> TS[0]	<input type="checkbox"/> TS[1]	<input type="checkbox"/> TS[2]	<input type="checkbox"/> TS[3]
<input type="checkbox"/> TS[4]	<input type="checkbox"/> TS[5]	<input type="checkbox"/> TS[6]	<input type="checkbox"/> TS[7]
<input type="checkbox"/> TS[8]	<input type="checkbox"/> TS[9]	<input type="checkbox"/> TS[10]	<input type="checkbox"/> TS[11]
<input type="checkbox"/> TS[12]	<input type="checkbox"/> TS[13]	<input type="checkbox"/> TS[14]	<input type="checkbox"/> TS[15]
<input type="checkbox"/> TS[16]	<input type="checkbox"/> TS[17]	<input type="checkbox"/> TS[18]	<input type="checkbox"/> TS[19]
<input type="checkbox"/> TS[20]	<input type="checkbox"/> TS[21]	<input type="checkbox"/> TS[22]	<input type="checkbox"/> TS[23]
<input type="checkbox"/> TS[24]	<input type="checkbox"/> TS[25]	<input type="checkbox"/> TS[26]	<input type="checkbox"/> TS[27]
<input type="checkbox"/> TS[28]	<input type="checkbox"/> TS[29]	<input type="checkbox"/> TS[30]	<input type="checkbox"/> TS[31]

Save

Close

Figure 3-33 Add PCM Trunk Interface




The interface is titled "PCM Trunk Batch Add". It features a section labeled "Including PCM:" with a "Check All" checkbox. Below this, there are four rows of checkboxes, each labeled with a PCM index: PCM[0] through PCM[15]. At the bottom of the interface are two buttons: "Save" and "Close".

Figure 3-34 PCM Trunk Batch Add Interface

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each PCM trunk
PCM NO.	The number of the PCM, numbered from 0.
Including Ts	Sets the TS included in this PCM which can make incoming/outgoing calls.
Including PCM	Sets the PCM included in the PCM trunk.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.




The interface shows a table titled "PCM Trunks" with columns: Check, Index, PCM NO., Including Ts, and Modify. It lists three items with indices 0, 1, and 2. Below the table are buttons for "Check All", "Uncheck All", "Inverse", "Delete", and "Clear All", along with an "Add New" button. At the bottom, it shows "3 Items Total", "20 Items/Page", and pagination controls.

Check	Index	PCM NO.	Including Ts	Modify
<input type="checkbox"/>	0	0	1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31	
<input type="checkbox"/>	1	1	1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31	
<input type="checkbox"/>	2	2	5	

Figure 3-35 PCM Trunks List

Click **Modify** in Figure 3-35 to modify a PCM trunk. The configuration items on the PCM Trunk Modification Interface are the same as those on the **Add PCM Trunk** interface.



The interface is titled "PCM Trunk". It contains the following fields and controls:

- Index:** A text input field with the value "0".
- PCM NO.:** A dropdown menu with the value "0".
- Including Ts:** A checkbox labeled "Check All" which is currently unchecked.
- TS Selection Grid:** A grid of 32 checkboxes labeled TS[0] through TS[31].
 - TS[0] is unchecked.
 - TS[1] through TS[15] are checked.
 - TS[16] is unchecked.
 - TS[17] through TS[31] are checked.
- Buttons:** "Save" and "Close" buttons at the bottom.

Figure 3-36 PCM Trunk Modification Interface

To delete a PCM trunk, check the checkbox before the corresponding index in Figure 3-35 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all PCM trunks at a time, click the **Clear All** button in Figure 3-35.

3.4.5 PCM Trunk Group


PCM Trunk Group					
Check	Index	PCM Trunks	PCM Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>					

Figure 3-37 PCM Trunk Group Settings

See Figure 3-37 for the PCM trunk group settings interface. A new PCM trunk group can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-38 for the PCM trunk group adding interface.

The image shows a 'PCM Trunk Group' configuration window. It has a title bar with the text 'PCM Trunk Group'. Inside, there are several input fields: 'Index' is a dropdown menu currently showing '1'; 'Description' is a text box containing 'default'; 'PCM Trunk Select Mode' is a dropdown menu currently showing 'Increase'; and 'PCM Trunks' is a section with a 'Check All' checkbox and three individual checkboxes labeled '0', '1', and '2'. At the bottom of the window are two buttons: 'Save' and 'Close'.

Figure 3-38 Add New PCM Trunk Group


The table below explains the items shown in Figure 3-38.

Item	Description										
Index	The unique index of each PCM trunk group, which is mainly used in the configuration of routing rules and number manipulation rules to correspond to PCM trunk groups.										
Description	More information about each PCM trunk group.										
PCM Trunk Select Mode	<p>When the PCM trunk group receives a call, it will choose a PCM trunk based on the select mode set by this configuration item to ring. The optional values and their corresponding meanings are described in the table below.</p> <table border="1"> <thead> <tr> <th>Option</th><th>Description</th></tr> </thead> <tbody> <tr> <td><i>Increase</i></td><td>Search for an idle PCM trunk in the ascending order of the PCM number, starting from the minimum.</td></tr> <tr> <td><i>Decrease</i></td><td>Search for an idle PCM trunk in the descending order of the PCM number, starting from the maximum.</td></tr> <tr> <td><i>Cyclic Increase</i></td><td>Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the ascending order of the PCM number, starting from PCM Trunk N+1.</td></tr> <tr> <td><i>Cyclic Decrease</i></td><td>Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the descending order of the PCM number, starting from PCM trunk N-1.</td></tr> </tbody> </table>	Option	Description	<i>Increase</i>	Search for an idle PCM trunk in the ascending order of the PCM number, starting from the minimum.	<i>Decrease</i>	Search for an idle PCM trunk in the descending order of the PCM number, starting from the maximum.	<i>Cyclic Increase</i>	Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the ascending order of the PCM number, starting from PCM Trunk N+1.	<i>Cyclic Decrease</i>	Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the descending order of the PCM number, starting from PCM trunk N-1.
Option	Description										
<i>Increase</i>	Search for an idle PCM trunk in the ascending order of the PCM number, starting from the minimum.										
<i>Decrease</i>	Search for an idle PCM trunk in the descending order of the PCM number, starting from the maximum.										
<i>Cyclic Increase</i>	Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the ascending order of the PCM number, starting from PCM Trunk N+1.										
<i>Cyclic Decrease</i>	Provided PCM Trunk N is the available PCM trunk found last time. Search for an idle PCM trunk in the descending order of the PCM number, starting from PCM trunk N-1.										
PCM Trunks	The PCM trunks in the PCM trunk group. If the checkbox before a PCM trunk is grey, it indicates that the PCM trunk has been occupied. The ticked PCM trunks herein will be displayed in the column 'PCM Trunks' in Figure 3-37.										

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-37 to modify a PCM trunk group. See Figure 3-39 for the PCM trunk group modification interface. The configuration items on this interface are the same as those on

the **Add New PCM Trunk Group** interface.



The interface is titled "PCM Trunk Group". It contains the following fields and controls:


- Index:** A text box containing the value "0".
- Description:** A text box containing the value "default".
- PCM Trunk Select Mode:** A dropdown menu currently set to "Increase".
- PCM Trunks:** A section with a "Check All" checkbox and three individual checkboxes for indices 0, 1, and 2. The checkbox for index 0 is checked.
- Buttons:** "Save" and "Close" buttons at the bottom.

Figure 3-39 Modify PCM Trunk Group

To delete a PCM trunk group, check the checkbox before the corresponding index in Figure 3-37 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all PCM trunk groups at a time, click the **Clear All** button in Figure 3-37.

3.4.6 Number-receiving Rule

The gateway uses a number-receiving plan to filter the numbers received from PSTN. Only those numbers which match the plan will be processed. The number-receiving plan consists of multiple number-receiving rules, each of which has a priority in sequence to avoid conflict.



The interface is titled "Number-receiving Rule". It displays a table with the following columns: Check, Index, Number-receiving Rule, Description, and Modify.

Check	Index	Number-receiving Rule	Description	Modify
<input type="checkbox"/>	99	.	example	

Below the table, there are action buttons: Check All, Uncheck All, Inverse, Delete, Clear All, and Add New.

At the bottom, there is a pagination bar showing: 1 Items Total, 20 Items/Page, 1/1, First, Previous, Next, Last, Go to Page 1, 1 Pages Total.

A note at the bottom states: Rule: "X"(lowercase) indicates a random number, "." indicates multiple random characters.

Figure 3-40 Number-Receiving Rule Configuration Interface

See Figure 3-40 for the Number-receiving Rule Configuration interface. The list in the above figure shows the number-receiving rules with their priorities and description. A new number-receiving rule can be added by the **Add New** button on the bottom right corner. See Figure 3-41 for the number-receiving rule adding interface.




Figure 3-41 Add New Number-Receiving Rule

The table below explains the items shown in Figure 3-41.

Item	Description
<i>Index</i>	The unique index of each number-receiving rule, which denotes its priority. A number-receiving rule with a smaller index value has a higher priority and will be checked earlier while matching.

Number-Receiving Rule

Up to 99 number-receiving rules can be configured in the gateway, and the maximum length of each number-receiving rule is 127 characters. See below for the meaning of each character in the number-receiving rule. The gateway will do instant matching for your receiving number based on the number-receiving rule and regard your receiving as finished upon receiving '#' or reception timeout.

Character	Description
"0"~"9"	Digits 0~9.
"x"	A random number. A string of 'x's represents several random numbers. For example, 'xxx' denotes 3 random numbers.
"."	'.' indicates a random amount (including zero) of characters after it.
"["	'[' is used to define the range for a number. Values within it only can be digits '0~9', punctuations '-' and ','. For example, [1-3,6,8] indicates any one of the numbers 1, 2, 3, 6, 8.
"_"	'_' is used only in '[' between two numbers to indicates any number between these two numbers.
","	',' is used to separate numbers or number ranges, representing alternatives.

By default, there is only one rule configured on the gateway. The table below lists 20 rules as example for your easy use and understanding. See below for detailed information.

Priority	Dialing Rule	Description
99	.	Any number in any length.
98	01[3,5,8]xxxxxxxxx.	Any 12-digit number starting with 013, 015 or 018
97	010xxxxxxxxx	Any 11-digit number starting with 010
96	02xxxxxxxxx	Any 11-digit number starting with 02
95	0[3-9]xxxxxxxxx	Any 12-digit number starting with 03, 04, 05, 06, 07, 08 or 09
94	120	Number 120
93	11[0,2-9]	Number 110, 112, 113, 114, 115, 116, 117, 118 or 119
92	111xx	Any 5-digit number starting with 111
91	123xx	Any 5-digit number starting with 123
90	95xxx	Any 5-digit number starting with 95
89	100xx	Any 5-digit number starting with 100
88	1[3-5,8]xxxxxxxxx	Any 11-digit number starting with 13, 14, 15 or 18
87	[2-3,5-7]xxxxxxx	Any 8-digit number starting with 2, 3, 5, 6 or 7
86	8[1-9]xxxxxx	Any 8-digit number starting with 81, 82, 83, 84, 85, 86, 87, 88 or 89

	85	80[1-9]xxxxx	Any 8-digit number starting with 801, 802, 803, 804, 805, 806, 807, 808 or 809
	84	800xxxxxxx	Any 10-digit number starting with 800
	83	4[1-9]xxxxxx	Any 8-digit number starting with 41, 42, 43, 44, 45, 46, 47, 48 or 49.
	82	40[1-9]xxxxx	Any 8-digit number starting with 401, 402, 403, 404, 405, 406, 407, 408 or 409
	81	400xxxxxxx	Any 10-digit number starting with 400
	80	8xxx	Any 4-digit number starting with 8
Description	Remarks for the number-receiving rule. It can be any information, but can not be left empty.		

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-40 to modify the number-receiving rules. See Figure 3-42 for the number-receiving rule modification interface. The configuration items on this interface are the same as those on the **Add New Number-receiving Rule** interface.

Figure 3-42 Modify Number-receiving Rule

To delete a number-receiving rule, check the checkbox before the corresponding index in Figure 3-40 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number-receiving rules at a time, click the **Clear All** button in Figure 3-40.

3.4.7 Reception Timeout

Number-receiving Timeout Info		
Inter Digit Timeout (s)	Description	Modify
6	example	

Figure 3-43 Number-receiving Timeout Info Interface

See Figure 3-43 for the number-receiving timeout info interface. The table below explains the

items shown in the above figure.

Item	Description
Inter Digit Timeout	Sets the largest interval between two digits of a receiving number. Range of value: 1~10, calculated by s, with the default value of 6. In case your number-receiving rules do not include ".", the call will fail if there is no digit received or no number-receiving rule matched during this interval; in case your number-receiving rules include ".", the gateway will wait until this interval ends and match to the number-receiving rule "." if there is no digit received or no other number-receiving rule matched during this interval.
Description	More information about the configuration item Inter Digit Timeout , such as the reason for adopting the current value.

Click **Modify** in Figure 3-43 to modify the number-receiving timeout info. See Figure 3-44 for the number-receiving timeout info modification interface. The configuration items on this interface are the same as those on the **Number-receiving Timeout Info Interface**.

Figure 3-44 Modify Number-receiving Timeout Info

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

3.5 SS7 Settings

Users can see the SS7 option in the menu only when the configuration item **Signaling Protocol** on the PCM settings interface is set to **SS7-TUP** or **SS7-ISUP**. SS7 Settings includes eight parts: **SS7**, **TUP**, **TUP Number Param**, **ISUP**, **Number Param**, **Original CalleeID Pool**, **Redirecting Number Pool (Hidden item)** and **SS7 Server**. See Figure 3-45.




Figure 3-45 SS7 Settings

3.5.1 SS7

Figure 3-46 SS7 Settings Interface

See Figure 3-46 for the SS7 settings interface where you can configure the general SS7 parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-46.

Item	Description
As Client Only	Sets whether the gateway serves as Client only or not. If it is set to <i>No</i> (default), the SS7 server will be disabled.
Master IP	Sets the IP address of the master SS7 server, with the default value of 127.0.0.1, which indicates that there is only one SS7 server available.
Slave IP	Sets the IP address of the slave SS7 server. Only when the item Dual Gateway is ticked can this item be configured.
Local IP Address	Sets the IP address of the local PC, with the default value of 127.0.0.1.

Dual Gateway	If this feature is enabled, two SS7 servers are used at the same time in the system. The configuration items Master IP and Slave IP are respectively used to set the IP addresses of the master and slave servers.
---------------------	--

3.5.2 TUP

Figure 3-47 TUP Settings Interface

See Figure 3-47 for the TUP settings interface. Users can see this interface and configure the general TUP parameters only when the configuration item **Signaling Protocol** on the PCM settings interface is set to **SS7-TUP**. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-47.

Item	Description
Send GRM Group Message Using All-0 Field	If this configuration item is enabled, when the local driver sends the circuit group message to the remote PBX, this message covers all time slots TS1~31. By default this item is enabled.
Send ST Signal with CallerID in Outgoing Call	If this configuration item is enabled, the calling party number string sent by the gateway contains the ST signal in the outgoing call. By default this item is disabled.
Default Caller Parameter	Sets the address indicator in the calling line identification field in the IAI message. The optional values are: <i>Local subscriber number</i> , <i>Spare national number</i> , <i>Valid national number</i> and <i>International number</i> , with the default value of <i>Valid national number</i> .

<i>Set Caller Parameter in case of Original CalleeID</i>	Once this feature is enabled, if the IP end carries the original CalleeID in a call from IP to PSTN, you shall set a separate value for the address indicator in the calling line identification field in the IAI message, i.e. <i>Caller Parameter (with Original CalleeID)</i> . By default this configuration item is disabled.
<i>Caller Parameter (with Original CalleeID)</i>	This item is valid only when <i>Set Caller Parameter in case of Original CalleeID</i> is enabled. It sets the address indicator in the calling line identification field in the IAI message when the IP end carries the original CalleeID in a call from IP to PSTN. The optional values are: <i>Local subscriber number</i> , <i>Spare national number</i> , <i>Valid national number</i> and <i>International number</i> , with the default value of <i>Valid national number</i> .
<i>Default Original Callee Parameter</i>	Sets the address indicator in the original called party address field of the IAI message. The optional values are: <i>Local subscriber number</i> , <i>Spare national number</i> , <i>Valid national number</i> and <i>International number</i> , with the default value of <i>Valid national number</i> .
<i>Maximum Wait Answer Time (s)</i>	Sets the maximum time to wait for the answer from the called party of an outgoing call. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 60, calculated by s.
<i>Minimum Length of the CalleeID of an Incoming Call</i>	Sets the minimum length of the CalleeID under the fixed-length mode. The value range is $1 \leq n \leq 40$. Provided it is set to n, that is, the local end has received all the n digits of the called party number of the incoming call, the number reception will be regarded as finished.

3.5.3 TUP Number Parameter

[illegible]

Figure 3-48 TUP Number Parameter Configuration Interface

See Figure 3-48 for the TUP Number Parameter Configuration interface, which is used to set the corresponding parameters for the calling party number in TUP.

A new TUP number parameter can be added by the **Add New** button. See Figure 3-49 for the calling party number adding interface.




Figure 3-49 Add New Calling Party Number Parameter

The table below explains the items shown in the above figure.

Item	Description
No.	The corresponding number for a calling party number parameter, which starts from 0.
Prefix	A string of numbers at the beginning of a calling party number.
Parameter	Sets the parameter for a calling party number.
Set Parameter if Original CalleeID Available	Set whether to enable the feature of setting this parameter only if the original CalleeID is available.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-48 to modify the calling party number parameter. See Figure 3-50 for the calling party number parameter modification interface. The configuration items on this interface are the same as those on the **Add New Calling Party Number Parameter** interface.





Figure 3-50 Modify Calling Party Number Parameter

To delete a calling party number parameter, check the checkbox before the corresponding index in Figure 3-48 and click the '**Delete**' button. To clear all calling party number parameters at a time, click the **Clear All** button in Figure 3-48.

Note: If there are two or more calling party numbers with the same prefix, the one numbered the smallest is valid and all the others become invalid.

3.5.4 ISUP



The ISUP Settings interface is a web-based configuration page. It features a title bar 'ISUP Settings' and a main content area with various parameters. Each parameter has a label on the left and a control on the right. The controls include dropdown menus, checkboxes, and text input fields. At the bottom, there are 'Save' and 'Reset' buttons.

Parameter	Value	Enable/Disable
Calling Party's Category	Ordinary calling subscriber	
Default Caller Parameter	Subscriber number 0x1301	
Default Callee Parameter	National number 0x1003	
Set Caller/Callee Parameter in case of Original CalleeID	<input checked="" type="checkbox"/> Enable	
Caller Parameter (with Original CalleeID)	National number 0x1003	
Callee Parameter (with of Original CalleeID)	International number 0x1004	
Default Original Callee Parameter	National Number	
Send Generic Number	<input type="checkbox"/> Enable	
Transmission Medium Requirement	Speech	
Obtain First Called Party Number from	Original calleeID/Redirecting nur	
Auto Reply INF upon Reception of Remote INR	<input checked="" type="checkbox"/> Enable	
Reset Circuit upon Service Start before Entering Idle State	<input checked="" type="checkbox"/> Enable	
Information on First Two Bytes of Redirecting Number	0x1001	
Maximum Wait Answer Time (s)	180	
Minimum Length of the CalleeID of an Incoming Call	1	
Forward Call Indicator	0x0040	
Nature of Connection Indicator	0x00	
User Service Information	0x80,0x90,0xa3 <input type="checkbox"/> Enable	
Optional Forward Call Indicator	0x00 <input type="checkbox"/> Enable	

Figure 3-51 ISUP Settings Interface


See Figure 3-51 for the ISUP settings interface. Users can see this interface and configure the general ISUP parameters only when the configuration item **Signaling Protocol** on the PCM settings interface is set to **SS7-ISUP**. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-51.

Item	Description
------	-------------


Calling Party's Category	Sets the calling party's category indicator in the IAM message. The optional values are: <i>National operator</i> , <i>Ordinary calling subscriber</i> , <i>Calling subscriber with priority</i> , <i>Data call</i> , <i>Test call</i> and <i>Payphone/Others</i> , with the default value of <i>Ordinary calling subscriber</i> .
Default Caller Parameter	Sets the calling party number parameter field in the IAM message. The optional values are: <i>Subscriber number</i> , <i>National number</i> , and <i>International number</i> , with the default value of <i>Subscriber number</i> .
Default Callee Parameter	Sets the called party number parameter field in the IAM message. The optional values are: <i>Subscriber number</i> , <i>National number</i> , and <i>International number</i> , with the default value of <i>National number</i> .
Set Caller/Callee Parameter in case of Original CalleeID	Once this feature is enabled, if the IP end carries the original CalleeID in a call from IP to PSTN, you shall set separate values for the caller and callee parameters in the IAM message, i.e. Caller Parameter (with Original CalleeID) and Callee Parameter (with Original CalleeID) . By default this configuration item is disabled.
Caller Parameter (with Original CalleeID)	This item is valid only when Set Caller/Callee Parameter in case of Original CalleeID is enabled. It sets the calling party number parameter field in the IAM message when the IP end carries the original CalleeID in a call from IP to PSTN. The optional values are: <i>Subscriber number</i> , <i>National number</i> , and <i>International number</i> , with the default value of <i>Subscriber number</i> .
Callee Parameter (with Original CalleeID)	This item is valid only when Set Caller/Callee Parameter in case of Original CalleeID is enabled. It sets the called party number parameter field in the IAM message when the IP end carries the original CalleeID in a call from IP to PSTN. The optional values are: <i>Subscriber number</i> , <i>National number</i> , and <i>International number</i> , with the default value of <i>National number</i> .
Default Original Callee Parameter	Sets the first two bytes of the original called party number in the IAM message, including the nature of address indicator, numbering plan indicator and address presentation restricted indicator, with the default value of 0x1001.
Send Generic Number	Sets the generic number parameter in IAM message, with the default value of <i>disabled</i> .
Transmission Medium Requirement	Sets the transmission medium requirement parameter in the IAM message. The optional values are: <i>Speech</i> , <i>64 kb/s unrestricted</i> , <i>3.1khz audio</i> , <i>Alternative: speech (service 2)/ 64kbit/s unrestricted (service 1) (Spare)</i> , <i>Alternative: 64kbit/s unrestricted (service 1)/ speech (service 2) (Spare)</i> , <i>64kb/s preferred</i> , <i>2*64kb/s unrestricted</i> , <i>384 kb/s unrestricted</i> , <i>1920 kb/s unrestricted</i> and <i>Spare</i> , with the default value of <i>Speech</i> .
Obtain First Called Party Number from	Sets where the first called party number is obtained from. The optional values are: <i>Only original CalleeID</i> and <i>Original CalleeID/ Redirecting number</i> , with the default value of <i>Only original CalleeID</i> .
Auto Reply INF upon Reception of Remote INR	If this feature is enabled, once the INR message is received from the remote PBX in an outgoing call, the driver will automatically reply it with the INF message. By default this feature is enabled.

Reset Circuit upon Service Start before Entering Idle State	If this feature is enabled, the circuit will send a circuit reset message before entering the idle state after the ISUP service is enabled. By default this feature is enabled.
Information on First Two Bytes of Redirecting Number	Sets the first two bytes of the redirecting number in the IAM message, including the nature of address indicator, numbering plan indicator and address presentation restricted indicator, with the default value of 0x1001.
Maximum Wait Answer Time (s)	Sets the maximum time to wait for the answer from the called party of an outgoing call. If the call is not answered within the specified time period, it will be canceled by the channel automatically. The default value is 180, calculated by s.
Minimum Length of the CalleeID of an Incoming Call	Sets the minimum length of the CalleeID under the fixed-length mode. The value range is $1 \leq n \leq 40$. Provided it is set to n, that is, the local end has received all the n digits of the called party number of the incoming call, the number reception will be regarded as finished.
Forward Call Indicator	Sets the forward call indicator in the IAM message, with the default value of 0x0040.
Nature of Connection Indicator	Sets the nature of connection indicator in the IAM message, with the default value of 0x00.
User Service Information	Sets whether the IAM message contains the user service information. By default this feature is disabled. If this feature is enabled, its value is usually determined by the remote PBX, with the default value of 0x80, 0x90, 0xa3. This default value is applicable to Huawei PBXes.
Optional Forward Call Indicator	Sets whether the IAM message contains the optional forward call indicator. By default this feature is disabled. If this feature is enabled, its value is usually determined by the remote PBX, with the default value of 0x00.

3.5.5 ISUP Number Parameter

Calling Party Number Parameter					
Check	No.	Prefix	Parameter	Set Parameter if Original CalleeID Available	Modify
<input type="checkbox"/>	0	1	0x1003	No	

Delete
...
Clear All
Add New

Called Party Number Parameter					
Check	No.	Prefix	Parameter	Set Parameter if Original CalleeID Available	Modify
<input type="checkbox"/>	0	6	0x1004	No	

Delete
...
Clear All
Add New

Note: You shall restart the service to validate the settings on this panel.

Figure 3-52 ISUP Number Parameter Configuration Interface

See Figure 3-52 for the ISUP Number Parameter Configuration interface, which includes two parts: **Calling Party Number Parameter** and **Called Party Number Parameter**.

A new calling/called party number parameter can be added by the **Add New** button. See Figure 3-53, Figure 3-54 for the calling/called party number parameter adding interface.




Figure 3-53 Add New Calling Party Number Parameter




Figure 3-54 Add New Called Party Number Parameter

The table below explains the items shown in above figures.

Item	Description
No.	The corresponding number for a calling/called party number parameter, which starts from 0.
Prefix	A string of numbers at the beginning of a calling/called party number.
Parameter	Sets the parameter for a calling/called party number.
Set Parameter if Original CalleeID Available	Set whether to enable the feature of setting this parameter only if the original CalleeID is available.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-52 to modify the calling/called party number parameter. See Figure 3-55, Figure 3-56 for the calling/called party number parameter modification interface. The configuration items on this interface are the same as those on the **Add New Calling/Called Party Number Parameter** interface.




Figure 3-55 Modify Calling Party Number Parameter




Figure 3-56 Modify Called Party Number Parameter

To delete a calling/called party number parameter, check the checkbox before the corresponding index in Figure 3-52 and click the '**Delete**' button. To clear all calling/called party number parameters at a time, click the **Clear All** button in Figure 3-52.

Note: If there are two or more calling/called party numbers with the same prefix, the one numbered the smallest is valid and all the others become invalid.

Original CalleeID Range	The range of the original CalleeID in the Original CalleeID Pool. It must be filled in with numbers and can not be left empty.
--------------------------------	--

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-57 to modify the calling/called party number parameter. See Figure 3-59, for the original CalleeID modification interface. The configuration items on this interface are the same as those on the **Add New Original CalleeID** interface. Note that the item **No.** cannot be modified.

Original CalleeID

No.:

0

CallerID Prefix:

*

CalleeID Prefix:

*

Original CalleeID Range:

100000000000000000

--

100000000000000001

Save

Close

Figure 3-59 Modify Original CalleeID

Note: If there are two or more calling/called party numbers with the same prefix, Starting Original CalleeID and Number Amount corresponding to the one numbered the smallest are valid and all the others become invalid.

3.5.7 Redirecting Number Pool (Hidden item)

[illegible]

Figure 3-60 Redirecting Number Pool Interface

After you enter `http://the IP address of your gateway/gfdhmc.php` in the address column of the browser, the redirecting number pool will appear on the web. See Figure 3-60 for the Redirecting

Number Pool interface, which is used to set the redirecting number in the setup message for all outgoing calls or some calls which contain a specified calling/called prefix. This feature is only applicable to ISUP calls.

A new redirecting number can be added by the Add New button. See Figure 3-61 for the redirecting number adding interface.

Figure 3-61 Add New Redirecting Number

The table below explains the items shown in above figures.

Item	Description
No.	The corresponding number for an added redirecting number. The value range is 0~99.
CallerID Prefix	A string of numbers at the beginning of a calling party number, which can be numbers or "*" (indicating any string).
CalleeID Prefix	A string of numbers at the beginning of a called party number, which can be numbers or "*" (indicating any string).
Redirecting Information	Sets the redirection information field in the IAM message. The parameter type of the redirection information field is 0x13, which contains 2 bytes. By default, it is set to 0x0321, i.e. call forwarding on no answer. Refer to the ISUP protocol standard for the detailed description of each byte.
Redirecting Number Range	The range of the redirecting number in the Redirecting Number Pool. It must be filled in with numbers and can not be left empty.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-60 to modify the redirecting number parameter. See Figure 3-62 for the redirecting number modification interface. The configuration items on this interface are the same as those on the **Add New Redirecting Number** interface. Note that the item **No.** cannot be modified.

Redirecting Number

No.:

CallerID Prefix:

CalleeID Prefix:

Redirection Information:

Redirecting Number Range:

--

Figure 3-62 Modify Redirecting Number

To delete a redirecting number parameter, check the checkbox before the corresponding index in Figure 3-60 and click the '**Delete**' button. To clear all redirecting number parameters at a time, click the **Clear All** button in Figure 3-60.

Note: If there are two or more calling/called party numbers with the same prefix, only the one numbered the smallest are valid for Starting Redirecting Number and Number Amount.

3.5.8 SS7 Server

Server 1 IP: Server 2 IP: Signaling Point Code Standard: Subservice Code:

Send SLTM: ☐ Enable 1

Client					Signaling Link				Signaling Linkset					DPC Settings					
Check	No.	IP Address	WEBPort	Modify	Check	No.	Physical Address	Modify	Check	No.	Link	OPC	Modify	Check	No.	STP	SP Code	Linkset	Mod
<input type="checkbox"/>	0	127.0.0.1	80		<input type="checkbox"/>	0	IP[0]:LINK[0]		<input type="checkbox"/>	0	0	1.2.3		<input type="checkbox"/>	0	Associated Mode	9.9.9	0	
2									3					4					
<input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>					<input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>				<input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>					<input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>					

TUP_CIC Route		ISUP_CIC Route		No.	DPC	CIC_PCM	CIC Range	Local PCM	SP Code	STP	Modify
<input type="checkbox"/>				0	0	0	0-31	IP[0]:PCM[0]	9.9.9	None	
<input type="checkbox"/>				1	0	1	32-63	IP[0]:PCM[1]	9.9.9	None	
<input type="checkbox"/>				2	0	2	64-95	IP[0]:PCM[2]	9.9.9	None	
<input type="checkbox"/>				3	0	3	96-127	IP[0]:PCM[3]	9.9.9	None	
5											
<input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>											

Note 1: The multi-signaling TS is supported from ver 1.6.2. We use LINK number to instead of the PCM number!
 Note 2: You shall restart the service to validate the settings on this page!

Figure 3-63 SS7 Server Configuration Interface

When the gateway uses the SS7 signaling, it must run the SS7 server first. See Figure 3-63 for

the SS7 configuration interface, where you can set the SS7 server configuration file (Ss7server.ini). Follow the instructions below to accomplish the configurations step by step.

Step 1: Set Server IP and Signaling Point Code Standard. See Region 1 in Figure 3-63.

The table below explains these configuration items.

Item	Description
Server 1 IP	Sets the IP address for the master SS7 server. If only one server is used in the system, there is no need to set the configuration item Server 2 IP .
Server 2 IP	Sets the IP address for the slave SS7 server.
Signaling Point Code Standard	The value of this item varies on the PBX model. The optional values are 14 and 24, with the default value of 24. The China SS7 uses 24.
Subservice Code	Sets the SS7 subservice code. The optional values are: <i>International network</i> , <i>Spare international network</i> , <i>National network</i> , <i>Spare national network</i> , with the default value of <i>Spare national network</i> .
Send SLTM	Sets whether to regularly send the Signaling Link Test Message (SLTM) to the remote PBX. By default it is disabled.

After configuration, click **Save** to save the settings into the gateway.

Step 2: Configure the client. See Region 2 in Figure 3-63.

A new client can be added by the **Add New** button on the bottom right corner of the client list. See Figure 3-64 for the new client adding interface.

Figure 3-64 Add New Client

The table below explains the configuration items in the above figure.

Item	Description
No.	The unique index of each client, which is mainly used in the configuration of signaling links to correspond to the client, numbered from 0.
IP Address	IP address of the client.
WEB Port	The port which is used to access the gateway via WEB. The default value is 80.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

To modify a client, click **Modify** in the client list. The configuration items on the modification interface are the same as those on the **Add New Client** interface.

To delete a client, check the checkbox before the corresponding index and click the **Delete** button under the list. To clear all clients at a time, click the **Clear All** button. Note: If a client is occupied by a signaling link, it cannot be deleted or cleared unless you delete the signaling link first. You can only delete the clients in turn from back to front.

Step 3: Configure signaling links and linksets. See Region 3 in Figure 3-63.

The link used to transmit signaling messages between two signaling points is called Signaling Link. Each signaling link maps a physical address. A new signaling link can be added by the **Add New** button on the bottom right corner of the signaling link list. See Figure 3-65 for the new signaling link adding interface.

Figure 3-65 Add New Signaling Link

The table below explains the configuration items in the above figure.

Item	Description
No.	The unique index of each signaling link, which is mainly used in the configuration of signaling linksets to correspond to the signaling link, numbered from 0.
Client	Client number. This configuration item together with PCM determines the physical address of the E1 interface of the signaling link. Each physical address maps a signaling link.
LINK	The number of the signaling time slot, which starts from 0.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

To modify a signaling link, click **Modify** in the signaling link list. The configuration items on the modification interface are the same as those on the **Add New Signaling Link** interface.

To delete a signaling link, check the checkbox before the corresponding index and click the **Delete** button under the list. To clear all signaling links at a time, click the **Clear All** button. Note: If a signaling link is occupied by a signaling linkset, it cannot be deleted or cleared unless you delete the signaling linkset first. You can only delete the signaling links in turn from back to front.

A group of signaling links used to connect two signaling points directly constitute a signaling linkset. A new signaling linkset can be added by the **Add New** button on the bottom right corner of the signaling linkset list. See Figure 3-66 for the new signaling linkset adding interface.

Figure 3-66 Add New Signaling Linkset

The table below explains the configuration items in the above figure.

Item	Description		
No.	The unique index of each signaling linkset, which is mainly used in the configuration of DPC to correspond to the signaling linkset, numbered from 0.		
Link	The signaling links in the linkset. If the checkbox before a link is grey, it indicates that the link has been occupied.		
OPC	Originating Point Code for the signaling server which is usually allocated by the central office,. See the table below for the format and the value range:		
		14 bit	24 bit
	Decimal (a.b.c)	a, c: 0~7, b: 0~255	a, b, c: 0~255
	Hexadecimal (abc)	a, c: 3-digit hexadecimal number, b: 8-digit hexadecimal number	a, b, c: hexadecimal number inbetween 00~ff

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

To modify a signaling linkset, click **Modify** in the signaling linkset list. The configuration items on the modification interface are the same as those on the **Add New Signaling Linkset** interface.

To delete a signaling linkset, check the checkbox before the corresponding index and click the **Delete** button under the list. To clear all signaling linkset at a time, click the **Clear All** button. Note: If a signaling linkset is occupied by a DPC, it cannot be deleted or cleared unless you delete the DPC first. You can only delete the signaling linksets in turn from back to front.

Step 4: Configure DPC. See Region 4 in Figure 3-63.

The signaling point that receives messages is called Destination Point Code (DPC). A new DPC can be added by the **Add New** button on the bottom right corner of the DPC list. See Figure 3-67 for the new DPC adding interface.






Figure 3-67 Add New DPC

The table below explains the configuration items in the above figure.

Item	Description
No.	The unique index of each DPC, which is mainly used in the configuration of TUP_CIC Route or ISUP_CIC Route to correspond to the DPC, numbered from 0.
Associated Mode/ Quasi-associated Mode	<p>Sets the way to transmit signaling messages between two signaling points, including <i>Associated Mode</i> and <i>Quasi-associated Mode</i>. Directly connecting the signaling links between two signaling points to transmit the inbetween signaling messages is called Associated Mode. Connecting two or more than two signaling links serially via one or more than one signaling transport points to transmit signaling messages, provided the path of signaling messages through the signaling network is predetermined and fixed within a certain period of time, is called Quasi-associated Mode. These two concepts are vividly illustrated below.</p> <div style="display: flex; align-items: center; justify-content: center;">   <div style="border: 1px solid black; padding: 5px; margin-left: 20px;"> <p>Legend:</p> <p>..... Signaling Relationship</p> <p>—— Signaling Link Set</p> </div> </div> <p style="text-align: center;">(a) Associated Mode (b) Quasi-associated Mode</p>
SP Code	Signaling point code of the DPC, usually allocated by the central office.
STP	Sets the first STP (signaling transport point) the signaling message reaches during the transmission under the quasi-associated mode. Only when you select the quasi-associated mode can this item be seen and configured.
Linkset	The linkset which is used to transmit signaling messages. For the associated mode, this item sets the signaling linksets between the OPC and the DPC. For the quasi-associated mode, this item sets the signaling linksets between the OPC and the first STP (signaling transport point).

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

To modify a DPC, click **Modify** in the DPC list. The configuration items on the modification interface are the same as those on the **Add New DPC** interface.

To delete a DPC, check the checkbox before the corresponding index and click the **Delete** button under the list. To clear all DPCs at a time, click the **Clear All** button. Note: If a DPC is occupied by a CIC routing rule, it cannot be deleted or cleared unless you delete the routing rule first. You can only delete the DPCs in turn from back to front.

Step 5: Configure TUP_CIC or ISUP_CIC Route. See Region 5 in Figure 3-63.

A new TUP_CIC routing rule can be added by the **Add New** button on the bottom right corner of the TUP_CIC routing rule list. See Figure 3-68 for the new TUP_CIC routing rule adding interface.




Figure 3-68 Add New TUP_CIC Routing Rule

The table below explains the configuration items in the above figure.

Item	Description
No.	The unique index of each CIC routing rule, which is numbered from 0.
DPC	DPC used in the routing rule.
CIC_PCM	PCM number in the CIC field and the value is obtained by dividing the initial CIC number from the central office by 32.
CIC_PCM Range	Range of the PCM time slots corresponding to CIC.
Client	Client number. This configuration item together with PCM determines the local PCM in the CIC routing rule.
PCM	PCM number on the client.

Consecutively add _CIC_PCM for this DPC	Consecutively adds one or more CIC_PCM routes for a DPC.
--	--

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

To modify a routing rule, click **Modify** in the TUP_CIC routing rule list. The configuration items on the modification interface are the same as those on the **Add New TUP_CIC Routing Rule** interface.

To delete a routing rule, check the checkbox before the corresponding index and click the **Delete** button under the list. To clear all routing rules at a time, click the **Clear All** button.

For the ISUP_CIC route settings, click the ISUP_CIC Route tab in Region 5 in Figure 3-63. See Figure 3-69 for the ISUP_CIC route settings interface. The configuration items and operations on this interface are absolutely the same as those in the TUP_CIC route settings interface. Note: Besides the default setting, the CIC Range for ISUP_CIC route can also be user-defined.

Figure 3-69 ISUP_CIC Route Settings Interface

After completing the configurations on **SS7 Server Configuration Interface** (Figure 3-63), you shall restart the service to validate them. Refer to [3.12.18 Restart](#) for detailed instructions.

3.6 ISDN Settings

Users can see the ISDN option in the menu only when the configuration item **Signaling Protocol** on the PCM settings interface is set to *ISDN User Side* or *ISDN Network Side*. See Figure 3-70.




Figure 3-70 ISDN Settings

3.6.1 ISDN

Figure 3-71 ISDN Settings Interface

See Figure 3-71 for the ISDN settings interface where users can configure the general ISDN parameters. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-71.

Item	Description
TEI	Terminal Equipment Identifier, which is used to identify the service access point in the point-to-point data link connection. Range of value: 0~63, with the default value of 0. Note: The TEI values at the corresponding user side and the network side must be the same.
Ch Identification	Sets the way to represent channel identification messages on the digital trunk. The optional values are: <i>Number</i> and <i>Time slot diagram</i> , with the default value of <i>Number</i> .
Default Callee Type	Sets the type of number and numbering scheme for the called party numbers in the SETUP message during the outgoing call. The optional values are: <i>National number</i> , <i>International number</i> , <i>Network number</i> , <i>Subscriber number</i> and <i>Unknown</i> , with the default value of <i>National number</i> .
Default Caller Type	Sets the type of number and numbering scheme for the calling party numbers in the SETUP message during the outgoing call. The optional values are: <i>National number</i> , <i>International number</i> , <i>Network number</i> , <i>Subscriber number</i> and <i>Unknown</i> , with the default value of <i>National number</i> .

CODEC	Sets the voice CODEC used on the digital trunk. The optional values are <i>A-Law</i> and <i>u-Law</i> , with the default value of <i>A-Law</i> .
Auto Link Building	Sets whether to send the message of automatic link building for the ISDN at ISDN user side or network side. By default this feature is enabled.
CRC Check	Sets whether to enable the feature of CRC check for the digital trunk at ISDN user side or network side. By default this feature is enabled.
Set Caller/Callee Type in case of Redirecting Num	Once this feature is enabled, if the IP end carries the redirecting number in a call from IP to PSTN, you shall set separate values for the type of number and numbering scheme for the calling and called party numbers in the SETUP message, i.e. Callee Type (with Redirecting Num) and Caller Type (with Redirecting Num) . By default this configuration item is disabled.
Callee Type (with Redirecting Num)	This item is valid only when Set Caller/Callee Type in case of Redirecting Num is enabled. It sets the type of number and numbering scheme for the called party numbers in the SETUP message when the IP end carries the redirecting number in a call from IP to PSTN. The optional values are: <i>National number</i> , <i>International number</i> , <i>Network number</i> , <i>Subscriber number</i> and <i>Unknown</i> , with the default value of <i>National number</i> .
Caller Type (with Redirecting Num)	This item is valid only when Set Caller/Callee Type in case of Redirecting Num is enabled. It sets the type of number and numbering scheme for the calling party numbers in the SETUP message when the IP end carries the redirecting number in a call from IP to PSTN. The optional values are: <i>National number</i> , <i>International number</i> , <i>Network number</i> , <i>Subscriber number</i> and <i>Unknown</i> , with the default value of <i>National number</i> .
Transfer Capability	Sets the 'Transfer Capability' filed in the signaling message. The optional values are <i>Voice</i> and <i>3.1k Audio</i> , with the default value of <i>Voice</i> .
Enter Auto Alert State upon Reception of 'CALL PROCEEDING' Message	If this item is checked, the system will go into the state of auto alert when it receives the 02 (CALL PROCEEDING) message and the progress indicator turns to be 8 or 1. By default this item is disabled.
Enter Auto Alert State upon Reception of 'PROGRESS' Message	If this item is checked, the system will go into the state of auto alert when it receives the 03 (PROGRESS) message and the progress indicator turns to be 8 or 1. By default this item is disabled.
Maximum Wait Time for Called Party's Pick up	The maximum time waiting for the called party to pick up the call after the channel state turns to 'WaitAnswer' during an outgoing call. The default value is 60, calculated by s.
Minimum Length of the CalleeID of an Incoming Call	Sets the minimum length of the CalleeID under the fixed-length mode. The value range is $1 \leq n \leq 40$. Provided it is set to n, that is, the local end has received all the n digits of the called party number of the incoming call, the number reception will be regarded as finished.
Preferential Channel Selection	Sets whether to allow the preferential channel selection. By default this item is unchecked.

Send Channel Identification Message	Sets whether the channel identification message is included in the corresponding reply message (such as CALL PROCEEDING, ALERT, etc.) after the local end receives the SETUP message from the remote PBX during an incoming call. By default this item is checked.
Wait Confirm Time (T310)	Sets the maximum time that the local end waits for the remote end to send back the acknowledgement message in an outgoing call. If no acknowledgement message is received within the specified time period, the local end will disconnect the call automatically. For ISDN User Side, the default value is 15; for ISDN Network Side, the default value is 20, calculated by s.
Send the 'Called Party Number Completed' Parameter	Sets whether to include or not the 'Called Number Complete' parameter in the SETUP message during an outgoing call.

3.6.2 Number Parameter


Calling Party Number Type					
Check	No.	Prefix	Type	Set Parameter if Redirecting Number Available	Modify
<input type="checkbox"/>	0	6	0x11	Yes	

Called Party Number Type					
Check	No.	Prefix	Type	Set Parameter if Redirecting Number Available	Modify
<input type="checkbox"/>	0	1	0x91	Yes	

Delete	≡	Clear All	Add New	Delete	≡	Clear All	Add New
--------	---	-----------	---------	--------	---	-----------	---------

Figure 3-72 Number Parameter Configuration Interface

Number Parameter for ISDN is almost the same as that for SS7; only the calling/called party number changes from SS7 to ISDN; “set parameter if original CalleeID available” changes to “set parameter if redirecting number available” in ISDN. See Figure 3-72 for Number Parameter for ISDN. The configuration items on this interface are the same as those on Number Parameter for SS7 (Figure 3-53, Figure 3-54).



The image shows a 'Gateway IP' configuration window. It has a title bar 'Gateway IP'. Inside, there are three input fields: 'No.' with the value '0', 'IP' which is empty, and 'WEB Port' with the value '80'. At the bottom, there are two buttons: 'Save' and 'Close'.


Figure 3-75 Add New Gateway

The table below explains the items shown in above figures.

Item	Description
No.	The corresponding number for a new gateway, which starts from 0.
IP	The corresponding IP address for the new gateway, which must be in the same network section of the SIP address of WAN set via VoIP→SIP .
WEB Port	The port which is used to access the gateway via WEB. The default value is 80.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-74 to modify the gateway information. See Figure 3-76 for the gateway modification interface. The configuration items on this interface are the same as those on the **Add New Gateway** interface.



The image shows the same 'Gateway IP' configuration window as Figure 3-75, but with the 'IP' field filled with the address '201.123.112.221'. The 'No.' field is '0' and the 'WEB Port' field is '80'. The 'Save' and 'Close' buttons are at the bottom.

Figure 3-76 Modify Gateway Information

3.7 SS1 Settings

Figure 3-77 SS1 Settings Interface

See Figure 3-77 for the SS1 settings interface. This interface appears only when the configuration item **Signaling Protocol** on the PCM settings interface is set to SS1. You can set general information of SS1. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the items shown in Figure 3-77.

Item	Description
Country	Sets the country to use SS1, with the default value of <i>CHINA</i> .
ABCD Duration Timeout	Sets the minimum duration of ABCD signaling codes sent out by the remote PBX, calculated by millisecond (ms), which has to be the multiple of 8, with the default value of 0. Only when the on-line ABCD signaling codes vary and the new value keeps for more than the time specified by this configuration item will the gateway confirm the change of ABCD codes, Otherwise, the driver will believe there are undesired dithering signals on the line.
Max MFC Waiting Time	Sets the maximum waiting time, i.e. the timer T2 for the SS1 state machine, calculated by second, with the default value of 10.
CalleelD Length for Incoming Calls	Sets the way to receive the number, with the default value of 3 <i>which means receiving all the 3 digits of the called party number of the incoming call will put the local number reception into an end.</i>
KB Setting Timeout	Sets the maximum time to wait for the application to configure the KB signal, calculated by second, with the default value of 3.

KD Wait Time	Sets the maximum time to wait for the remote PBX to send the KD signal (i.e. the timer T3) in the SS1 channel state machine, calculated by second, with the default value of 60.
ACK Wait Timeout	Sets the value of the timer T5, calculated by second, with the default value of 60.
Calling Party's Category (KA Signal)	Sets the KA signal (calling party's category at the local end) sent in an outgoing call. The value range is 1~10, with the default value of 1 (<i>ordinary/regular</i>).
KB Wait Timeout	Sets the maximum time to wait for the KB signal from the remote PBX, calculated by second, with the default value of 60.
Originating Service Type (KD Signal)	Sets the originating service type, i.e. KD, for an outgoing call. The value range is 1~6, with the default value of 3 (<i>local call</i>).

3.8 Fax Settings

See Figure 3-78 for the Fax Settings interface which is used to modify the special fax configurations.



Figure 3-78 Fax Settings

3.8.1 Fax

Fax Parameters

Fax Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">T.38</div> ▼
T38 Version	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">0</div> ▼
T38 Negotiation	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">Initiate Negotiation as Fax Re</div> ▼
Maximum Fax Rate (bps)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">9600</div> ▼
Fax Train Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">transferredTCF</div> ▼
Error Correction Mode	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">t38UDPRedundancy</div> ▼
T.30 ECM	<input checked="" type="checkbox"/> Enable
Min Duration of CNG(ms)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">425</div>
Min Duration of CED(ms)	<div style="border: 1px solid #ccc; padding: 2px; display: inline-block;">2600</div>

Save

Reset

Figure 3-79 Fax Configuration Interface (T.38 Mode)

See Figure 3-79 for the fax configuration interface with all default settings under the T.38 fax mode. Users can configure the general fax parameters via this interface. After configuration, click **Save** to save your settings into the gateway or click **Reset** to restore the configurations. If a dialog box pops up after you save your settings asking you to restart the service, do it immediately to apply the changes. Refer to [3.12.18 Restart](#) for detailed instructions. The table below explains the configuration items in Figure 3-79.

Item	Description
Fax Mode	The real-time IP fax mode. The optional values are <i>T.38</i> , <i>Pass-through</i> and <i>Disable</i> , with the default value of <i>T.38</i> . Setting this item to <i>Disable</i> means to disable both T.38 and Pass-through.
T38 Version	Version of T.38 which is defined by ITU-T. Range of value: 0~3, with the default value of 0.
T38 Negotiation	Sets the Negotiation mode of T.38, including: <i>Unsupported</i> , <i>Initiate Negotiation as Fax Sender</i> and <i>Initiate Negotiation as Fax Receiver</i> .
Maximum Fax Rate	Sets the maximum faxing rate for both receiving and transmitting. Range of value: 14400, 9600 and 4800, calculated by bps, with the default value of 9600.
Fax Train Mode	Sets the train mode for T.38 fax. The optional values are <i>transferredTCF</i> and <i>localTCF</i> , with the default value of <i>transferredTCF</i> .
Error Correction Mode	Sets the error correction mode for T.38 fax. The optional values are <i>t38UDPRedundancy</i> (Redundancy Error Correction) and <i>t38UDPFEC</i> (Forward Error Correction), with the default value of <i>t38UDPRedundancy</i> .
T.30 Ecm	Sets whether to enable the T.30 error correction mode. By default this feature is enabled.
Min Duration of CNG	As stipulated in the standard FAX CNG, the minimum duration of CNG is 500ms \pm 15%, calculated by ms, with the default value of 425. Note: Usually there is no need to modify it; please contact our technicians if necessary.
Min Duration of CED	As stipulated in the standard FAX CED, the minimum duration of CED is 2600~4000ms, calculated by ms, with the default value of 2600. Note: Usually there is no need to modify it; please contact our technicians if necessary.

If you set **Fax Mode** to *Pass-through*, you can see the interface shown as Figure 3-80.

The screenshot shows a web-based configuration interface titled "Fax Parameters". It includes the following fields and controls:

- Fax Mode:** A dropdown menu currently showing "Pass-through".
- Pass-through Payload:** A text input field containing the value "102".
- Min Duration of CNG(ms):** A text input field containing the value "425".
- Min Duration of CED(ms):** A text input field containing the value "2600".
- Buttons:** Two buttons at the bottom, "Save" and "Reset", for applying or restoring default settings.

Figure 3-80 Fax Configuration Interface (Pass-through Mode)

The table below explains the configuration item in the above figure.

Item	Description
Pass-through Payload	RTP Payload under the pass-through fax mode. Range of value: 96~127, with the default value of 102.

3.9 Route Settings

Route Settings is used to specify the routing rules for calls on two directions: IP→PSTN and PSTN→IP. See Figure 3-81.




Figure 3-81 Route Settings

3.9.1 Routing Parameters




Figure 3-82 Routing Parameters Configuration Interface

See Figure 3-82 for the routing parameters configuration interface. On this interface, you can set the routing rules for calls respectively on two directions IP→PSTN and PSTN→IP to be routing before or after number manipulation. The default value is *Route before Number Manipulate*.

After configuration, click **Save** to save the above settings into the gateway.

3.9.2 IP to PSTN




Figure 3-83 IP→PSTN Routing Rule Configuration Interface

See Figure 3-83 for the IP→PSTN routing rule configuration interface. A new routing rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-84 for the IP→PSTN routing rule adding interface.


Figure 3-84 Add New Routing Rule (IP→PSTN)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Call Initiator	SIP trunk group from where the call is initiated. This item can be set to a specific SIP trunk group or SIP Trunk Group [ANY] which indicates any SIP trunk group.
CallerID Prefix, CalleeID Prefix	A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with Call Initiator can specify the calls which apply to a routing rule. Note: Multiple rules are supported for CallerID/CalleeID prefix. They are separated by ":".
Call Destination	PCM trunk group to which the call will be routed.
Number Filter	Number filter rule which will be applicable to this route. It is set in Number Filter . See 3.10.4 Filtering Rule for details.
Description	More information about each routing rule.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-83 to modify a routing rule. See Figure 3-85 for the IP→PSTN routing rule modification interface. The configuration items on this interface are the same as those on the **Add New Routing Rule (IP→PSTN)** interface. Note that the item **Index** cannot be modified.



The form is titled "IP->PSTN Routing Rule". It contains the following fields and values:

- Index: 255
- Call Initiator: SIP Trunk Group [0]
- CallerID Prefix: 333[1,3]:444[6,9]
- CalleeID Prefix: *
- Call Destination: PCM Trunk Group [0]
- Number Filter: none
- Description: default

At the bottom, there are two buttons: "Save" and "Close".

Figure 3-85 Modify Routing Rule (IP→PSTN)

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-83 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-83.

3.9.3 PSTN to IP


Routing Rules								
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Number Filter	Call Destination	Description	Modify
<input type="checkbox"/>	255	PCM Trunk Group [0]	*	*	none	SIP Trunk Group [0]	default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>								
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total								

Figure 3-86 PSTN→IP Routing Rule Configuration Interface

See Figure 3-86 for the PSTN→IP routing rule configuration interface. A new routing rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-87 for the PSTN→IP routing rule adding interface.


Figure 3-87 Add New Routing Rule (PSTN→IP)

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each routing rule, which denotes its priority. A routing rule with a smaller index value has a higher priority. If a call matches several routing rules, it will be processed according to the one with the highest priority.
Call Initiator	PCM trunk group from which the call is initiated. This item can be set to a specific PCM trunk group or PCM Trunk Group [ANY] which indicates any PCM trunk group.
CallerID Prefix, CalleeID Prefix	A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with Call Initiator can specify the calls which apply to a routing rule. Note: Multiple rules are supported in callerID/calleeID prefix. They should be separated by ":".
Call Destination	SIP trunk group to which the call will be routed.
Number Filter	Number filter rule which will be applicable to this route. It is set in Number Filter . See 3.10.4 Filtering Rule for detailed setting.
Description	More information about each routing rule.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-86 to modify a routing rule. See Figure 3-88 for the PSTN→IP routing rule modification interface. The configuration items on this interface are the same as those on the **Add New Routing Rule (PSTN→IP)** interface. Note that the item **Index** cannot be modified.



The image shows a configuration window titled "PSTN->IP Routing Rule". It contains several input fields and dropdown menus:

- Index:** A text box containing the value "255".
- Call Initiator:** A dropdown menu showing "PCM Trunk Group [0]".
- CallerID Prefix:** A text box containing the value "*".
- CalleeID Prefix:** A text box containing the value "*".
- Call Destination:** A dropdown menu showing "SIP Trunk Group [0]".
- Number Filter:** A dropdown menu showing "none".
- Description:** A text box containing the value "default".

At the bottom of the window, there are two buttons: "Save" and "Close".

Figure 3-88 Modify Routing Rule (PSTN→IP)

To delete a routing rule, check the checkbox before the corresponding index in Figure 3-86 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all routing rules at a time, click the **Clear All** button in Figure 3-86.

3.10 Number Filter

Number Filter includes four parts: **Whitelist**, **Blacklist**, **Number Pool** and **Filtering Rule**. See Figure 3-89.




Figure 3-89 Number Filter Interface

Figure 3-92 Add New CalleeIDs in Whitelist Interface

The table below explains the items shown in above figures.

Item	Description
Group	The corresponding Group ID for CallerIDs/CalleeIDs in the whitelist. The value range is 0~7.
No. in Group	The corresponding No. for different CallerIDs/CalleeIDs in a same group.
CallerID	CallerID in the whitelist, which must be filled in with numbers, "x" (indicating any single number) or "*" (indicating any string) and can not be left empty. Example: 135*1 denotes any CallerIDs which start from 135 and end with 1 will be accepted.
CalleeID	CalleeID in the whitelist, which must be filled in with numbers, "x" (indicating any single number) or "*" (indicating any string) and can not be left empty. Example: 135*1 denotes any CalleeIDs which start from 135 and end with 1 will be accepted.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-90 to modify the CallerID or CalleeID whitelist. See Figure 3-93, Figure 3-94 for CallerIDs/CalleeIDs on the Whitelist Modification interface. The configuration items on this interface are the same as those on the **Add New CallerIDs/CalleeIDs in Whitelist** interface. The item *Group No.* cannot be modified.

Figure 3-93 Modify CallerIDs in Whitelist

Figure 3-94 Modify CalleeIDs in Whitelist

Figure 3-97 Add New Number Pool

The table below explains the items shown in the above figure.

Item	Description
Group	The corresponding Group ID for numbers in the number pool. The value range is 0~15.
No. in Group	The corresponding No. for different numbers in a same group. It supports up to 100 numbers in one group.
Number Range	The range of the numbers in a number Pool. It must be filled in with numbers and can not be left empty.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-96 to modify the number pool. See Figure 3-98 for the number pool modification interface. The configuration items on this interface are the same as those on the **Add New Number Pool** interface.

Figure 3-98 Modify Number Pool Interface

To delete a number pool, check the checkbox before the corresponding index in Figure 3-96 and click the '**Delete**' button. To clear all number pools at a time, click the **Clear All** button in Figure

3-96.

3.10.4 Filtering Rule

Filtering Rule										
Check	No.	CallerID Whitelist	CalleeID Whitelist	CallerID Blacklist	CalleeID Blacklist	CallerID Pool in Whitelist	CallerID Pool in Blacklist	CalleeID Pool in Whitelist	CalleeID Pool in Blacklist	Original CallerID
<input type="checkbox"/>	0	0	none	none	none	0	none	none	none	
<input type="checkbox"/>	1	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	2	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	3	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	4	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	5	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	6	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	7	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	8	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	9	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	10	none	none	none	none	none	none	none	none	
<input type="checkbox"/>	11	none	none	none	none	none	none	none	none	

12 Items Total 15 Items/Page 1/1 First Previous Next Last Go to Page 1 Pages Total

Figure 3-99 Filtering Rule Setting Interface

See Figure 3-99 for the Filtering Rule Setting Interface. A new filtering rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-100 for the Filtering Rule Adding interface.

Filtering Rule

No.:

CallerID Whitelist:

none

CalleeID Whitelist:

none

CallerID Blacklist:

none

CalleeID Blacklist:

none

CallerID Pool in Whitelist:

none

CallerID Pool in Blacklist:

none

CalleeID Pool in Whitelist:

none

CalleeID Pool in Blacklist:

none

Original CalleeID Pool in Whitelist:

none

Original CalleeID Pool in Blacklist:

none

Description:

Save

Close

Figure 3-100 Add New Filtering Rule

The table below explains the items shown in the above figure.

Item	Description
No.	The corresponding number for a filtering rule. The value range is 0~99.
CallerID Whitelist	The Group No. of CallerIDs saved on the whitelist setting interface.
CalleeID Whitelist	The Group No. of CalleeIDs saved on the whitelist setting interface.
CallerID Blacklist	The Group No. of CallerIDs saved on the blacklist setting interface.
CalleeID Blacklist	The Group No. of CalleeIDs saved on the blacklist setting interface.
CallerID Pool in Whitelist	Select a Group No. which is set in the whitelist from the number pool as the CallerID pool in whitelist.
CallerID Pool in Blacklist	Select a Group No. which is set in the blacklist from the number pool as the CallerID pool in blacklist.
CalleeID Pool in Whitelist	Select a Group No. which is set in the whitelist from the number pool as the CalleeID pool in whitelist.

CalleeID Pool in Blacklist	Select a Group No. which is set in the blacklist from the number pool as the CalleeID pool in blacklist.
Original CalleeID Pool in Whitelist	Select a Group No. which is set in the whitelist from the number pool as the original CalleeID pool in whitelist.
Original CalleeID Pool in Blacklist	Select a Group No. which is set in the blacklist from the number pool as the original CalleeID pool in blacklist.
Description	Remarks for the filtering rule. It can be any information, but can not be left empty.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-99 to modify the filtering rule. See Figure 3-101 for the filtering rule modification interface. The configuration items on this interface are the same as those on the **Add New Filtering Rule** interface.

The 'Filtering Rule' interface includes the following configuration items:

- No.:** 0
- CallerID Whitelist:** 0
- CalleeID Whitelist:** none
- CallerID Blacklist:** none
- CalleeID Blacklist:** none
- CallerID Pool in Whitelist:** 0
- CallerID Pool in Blacklist:** none
- CalleeID Pool in Whitelist:** none
- CalleeID Pool in Blacklist:** none
- Original CalleeID Pool in Whitelist:** 0
- Original CalleeID Pool in Blacklist:** none
- Description:** default

Buttons: Save, Close

Figure 3-101 Modify Filtering Rule Interface

To delete a filtering rule, check the checkbox before the corresponding index in Figure 3-99 and

click the '**Delete**' button. To clear all filtering rules at a time, click the **Clear All** button in Figure 3-99.

3.11 Number Manipulation

Number Manipulation includes seven parts: **IP→PSTN CallerID**, **IP→PSTN CalleeID**, **IP→PSTN Original CalleeID**, **PSTN→IP CallerID**, **PSTN→IP CalleeID**, **PSTN→IP Original CalleeID** and **CallerID Pool**. See Figure 3-102.




Figure 3-102 Number Manipulation

3.11.1 IP to PSTN CallerID

Number Manipulation Rules												
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	SIP Trunk Group [0]	9	*	No	1	0	0			default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/> </div>												
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page <input type="text" value="1"/> 1 Pages Total												

Figure 3-103 IP→PSTN CallerID Manipulation Interface

See Figure 3-103 for the IP→PSTN CallerID manipulation interface. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-104 for the IP→PSTN CallerID manipulation rule adding interface.

IP->PSTN CallerID Manipulation

Index: 62

Call Initiator: SIP Trunk Group [0]

CallerID Prefix: *

CalleeID Prefix: *

With Original CalleeID: No

Stripped Digits from Left: 0

Stripped Digits from Right: 0

Reserved Digits from Right: 0

Prefix to Add:

Suffix to Add:

Description: default

Save Close

Figure 3-104 Add IP→PSTN CallerID Manipulation Rule

The table below explains the items shown in the above figure.


Item	Description
Index	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
Call Initiator	SIP trunk group from where the call is initiated. This item can be set to a specific SIP trunk group or SIP Trunk Group[ANY] which indicates any SIP trunk group.
CallerID Prefix, CalleeID Prefix	A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with Call Initiator and With Original CalleeID can specify the calls which apply to a number manipulation rule.
With Original CalleeID	If this item is set to Yes, it indicates that the number manipulation rule is only applicable to the calls with original CalleeID/redirecting number. The default value is No.

<i>Stripped Digits from Left</i>	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<i>Stripped Digits from Right</i>	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<i>Reserved Digits from Right</i>	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated.
<i>Prefix to Add</i>	Designated information to be added to the left end of the current number.
<i>Suffix to Add</i>	Designated information to be added to the right end of the current number.
<i>Description</i>	More information about each number manipulation rule.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: ***Stripped Digits from Left***, ***Stripped Digits from Right***, ***Reserved Digits from Right***, ***Prefix to Add*** and ***Suffix to Add***.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-103 to modify a number manipulation rule. See Figure 3-105 for the IP→PSTN CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add IP→PSTN CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.



The form is titled "IP->PSTN CallerID Manipulation". It contains the following fields and values:

- Index: 63
- Call Initiator: SIP Trunk Group [0]
- CallerID Prefix: 9
- CalleeID Prefix: *
- With Original CalleeID: No
- Stripped Digits from Left: 1
- Stripped Digits from Right: 0
- Reserved Digits from Right: 0
- Prefix to Add: (empty)
- Suffix to Add: (empty)
- Description: default

At the bottom, there are two buttons: "Save" and "Close".

Figure 3-105 Modify IP→PSTN CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-103 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-103.

3.11.2 IP to PSTN CalleeID

The number manipulation process for IP→PSTN CalleeID is almost the same as that for IP→PSTN CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-106 for IP→PSTN CalleeID manipulation interface. The configuration items on this interface are the same as those on **IP→PSTN CallerID Manipulation Interface** (Figure 3-103).


Number Manipulation Rules												
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	SIP Trunk Group [0]	*	*	No	0	0	0			default	
<input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> <input type="button" value="Add New"/>												
1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page <input type="text" value="1"/> 1 Pages Total												

Figure 3-106 IP→PSTN CalleeID Manipulation Interface

3.11.3 IP to PSTN Original CalleeID

The number manipulation process for IP→PSTN Original CalleeID is almost the same as that for IP→PSTN CallerID; only the number to be manipulated changes from CallerID to Original CalleeID. See Figure 3-107 for IP→PSTN Original CalleeID manipulation interface. The configuration items on this interface are the same as those on **IP→PSTN CallerID Manipulation Interface** (Figure 3-103).

Number Manipulation Rules											
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	SIP Trunk Group [0]	2	5	1	0	10	666	888	default	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-107 IP→PSTN Original CalleeID Manipulation Interface

3.11.4 PSTN to IP CallerID

Number Manipulation Rules											
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description
<input type="checkbox"/>	63	PCM Trunk Group [0]	89	*	No	2	0	0			default

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 3-108 PSTN→IP CallerID Manipulation Interface

See Figure 3-108 for the PSTN→IP CallerID manipulation interface. A new number manipulation rule can be added by the **Add New** button on the bottom right corner of the list in the above figure. See Figure 3-109 for the PSTN→IP CallerID manipulation rule adding interface.

PSTN->IP CallerID Manipulation

Index: 63

Call Initiator: PCM Trunk Group [0]

CallerID Prefix: *

CalleeID Prefix: *

With Original CalleeID: No

Stripped Digits from Left: 0

Stripped Digits from Right: 0

Reserved Digits from Right: 0

Prefix to Add:

Suffix to Add:

Description: default

Save Close

Figure 3-109 Add PSTN→IP CallerID Manipulation Rule

The table below explains the items shown in the above figure.

Item	Description
Index	The unique index of each number manipulation rule, which denotes its priority. A number manipulation rule with a smaller index value has a higher priority. If a call matches several number manipulation rules, it will be processed according to the one with the highest priority.
Call Initiator	PCM trunk group from where the call is initiated. This item can be set to a specific PCM trunk group or PCM Trunk Group[ANY] which indicates any PCM trunk group.
CallerID Prefix, CalleeID Prefix	A string of numbers at the beginning of the calling/called party number. This item can be set to a specific string or "*" which indicates any string. These two configuration items together with Call Initiator and With Original CalleeID can specify the calls which apply to the number manipulation rule.
With Original CalleeID	If this item is set to Yes, it indicates that the number manipulation rule is only applicable to the calls with original CalleeID/redirecting number. The default value is No.

<i>Stripped Digits from Left</i>	The amount of digits to be deleted from the left end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<i>Stripped Digits from Right</i>	The amount of digits to be deleted from the right end of the number. If the value of this item exceeds the length of the current number, the whole number will be deleted.
<i>Reserved Digits from Right</i>	The amount of digits to be reserved from the right end of the number. Only when the value of this item is less than the length of the current number will some digits be deleted from left; otherwise, the number will not be manipulated.
<i>Prefix to Add</i>	Designated information to be added to the left end of the current number.
<i>Suffix to Add</i>	Designated information to be added to the right end of the current number.
<i>Description</i>	More information about each number manipulation rule.

Note: The number manipulation is performed in 5 steps by the order of the following configuration items: ***Stripped Digits from Left***, ***Stripped Digits from Right***, ***Reserved Digits from Right***, ***Prefix to Add*** and ***Suffix to Add***.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-108 to modify a number manipulation rule. See Figure 3-110 for the PSTN→IP CallerID manipulation rule modification interface. The configuration items on this interface are the same as those on the **Add PSTN→IP CallerID Manipulation Rule** interface. Note that the item **Index** cannot be modified.

The image shows a configuration window titled "PSTN->IP CallerID Manipulation". It contains several input fields and dropdown menus for configuring a manipulation rule. The fields are as follows:

- Index:** 63
- Call Initiator:** PCM Trunk Group [0] (dropdown)
- CallerID Prefix:** 89
- CalleeID Prefix:** *
- With Original CalleeID:** No (dropdown)
- Stripped Digits from Left:** 2
- Stripped Digits from Right:** 0
- Reserved Digits from Right:** 0
- Prefix to Add:** (empty field)
- Suffix to Add:** (empty field)
- Description:** default

At the bottom of the window are two buttons: "Save" and "Close".

Figure 3-110 Modify PSTN→IP CallerID Manipulation Rule

To delete a number manipulation rule, check the checkbox before the corresponding index in Figure 3-108 and click the **Delete** button. **Check All** means to select all available items on the current page; **Uncheck All** means to cancel all selections on the current page; **Inverse** means to uncheck the selected items and check the unselected. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-108.

3.11.5 PSTN to IP CalleeID

The number manipulation process for PSTN→IP CalleeID is almost the same as that for PSTN→IP CallerID; only the number to be manipulated changes from CallerID to CalleeID. See Figure 3-111 for the PSTN→IP CalleeID manipulation interface. The configuration items on this interface are the same as those on **PSTN→IP CallerID Manipulation Interface** (Figure 3-108).

Number Manipulation Rules												
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description	Modify
<input type="checkbox"/>	63	PCM Trunk Group [0]	0	9	No	1	0	0			default	
<div> <input type="button" value="Check All"/> <input type="button" value="Uncheck All"/> <input type="button" value="Inverse"/> <input type="button" value="Delete"/> <input type="button" value="Clear All"/> </div> <div> 1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page <input type="text" value="1"/> 1 Pages Total </div> <div style="text-align: right;"><input type="button" value="Add New"/></div>												

Figure 3-111 PSTN→IP CalleeID Manipulation Interface

The number manipulation process for PSTN→IP Original CalleeID is almost the same as that for PSTN→IP CallerID; only the number to be manipulated changes from CallerID to Original CalleeID. See Figure 3-112 for the PSTN→IP Original CalleeID manipulation interface. The configuration items on this interface are the same as those on **PSTN→IP CallerID Manipulation Interface** (Figure 3-108).

Figure 3-112 PSTN→IP Original CalleeID Manipulation Interface

Manipulate IP->PSTN CallerIDs with
 Designated Prefix:

*

Set

IP->PSTN Manipulated CallerID Pool

Check	No.	CallerID	Outgoing Call Resource	Destination PCM	Modify

PSTN->IP Manipulated CallerID Pool

Check	No.	CallerID	Outgoing Call Resource	Modify

Delete

Clear All

Add New

Delete

Clear All

Add New

See Figure 3-113 for the CallerID Pool interface, including two parts: PSTN→IP Manipulated CallerID Pool and IP→PSTN Manipulated CallerID Pool. It is used to designate the CallerID for outgoing calls and restrict the call amount for each designated callerID at the same time. If it is set to manipulate IP→PSTN CallerIDs with the designated prefix, only those calls with the CallerID prefix set in the CallerID pool meeting the requirement can be able to go out. The item *Manipulate IP→PSTN CallerIDs with Designated Prefix* can not be left empty. By default it is set to “*”, that is, calls with any CallerID prefix can go out. A new CallerID can be added by the **Add New** button. See Figure 3-114 for the CallerID adding interface.





Figure 3-114 Add New CallerID Interface

The table below explains the items shown in above figures.

Item	Description
No.	The unique index of the CallerID in the pool, which starts from 0 and denotes its priority. A CallerID with a smaller index value has a higher priority.
CallerID	Sets the CallerID used for an outgoing call.
Outgoing Call Resource	Sets the maximum number of the outgoing calls for each CallerID.
Destination PCM	The calls outgoing from the PCM designated in this item will do the manipulation.
Batch Add	Sets the amount of CallerIDs to be batch added.

After configuration, click **Save** to save the above settings into the gateway or click **Close** to cancel the settings.

Click **Modify** in Figure 3-113 to modify the CallerID information. See Figure 3-115 for the CallerID modification interface. The configuration items on this interface are the same as those on the **Add New CallerID** interface. The item **No.** cannot be modified.



The image shows a web-based interface for modifying a CallerID. It has a dark header bar with the text "CallerID". Below the header, there are five input fields arranged vertically. The first field is labeled "No.:" and contains the value "0". The second field is labeled "CallerID:" and contains the value "100". The third field is labeled "Outgoing Call Resource:" and contains the value "5". The fourth field is labeled "Destination PCM:" and contains the value "random" with a dropdown arrow on the right. The fifth field is labeled "Batch Add:" and contains the value "1". At the bottom of the form, there are two buttons: a blue "Save" button and a grey "Close" button.

Figure 3-115 Modify CallerID Interface

To delete a CallerID in the pool, check the checkbox before the corresponding index in Figure 3-113 and click the '**Delete**' button. To clear all CallerIDs in the pool at a time, click the **Clear All** button in Figure 3-113.

3.12 System Tools

System Tools is mainly for gateway maintenance. It provides such features as IP modification, time synchronization, data backup, log inquiry and connectivity check. See Figure 3-116 for details.




Figure 3-116 System Tools

3.12.1 Network

The screenshot displays the 'Network Settings' window. It is divided into three main sections: LAN 1, LAN 2, and BOND Setting.

LAN 1 Configuration:

- IP Address (I): 201.123.112.26
- Subnet Mask (U): 255.255.255.0
- Default Gateway (D): 201.123.112.254
- DNS Server (P): 0.0.0.0
- Speed and Duplex Mode: Automatic Detection (dropdown menu)

LAN 2 Configuration:

- IP Address (I): 192.168.0.101
- Subnet Mask (U): 255.255.255.0
- Default Gateway (D): 192.168.0.254
- DNS Server (P): 0.0.0.0
- Speed and Duplex Mode: Automatic Detection (dropdown menu)

BOND Setting:

- BOND: ☒ Yes ☐ No
- BOND Address: LAN 1 (dropdown menu)

At the bottom of the window, there are two buttons: 'Save' and 'Reset'.

Figure 3-117 Network Settings Interface

See Figure 3-117 for the network settings interface. A gateway has two LANs, each of which can be configured with independent IP address, subnet mask, default gateway and DNS server. The Bond feature when enabled will make the information of LAN1 and LAN2 duplicated and backed up, so as to realize the hot-backup function between LAN1 and LAN2. By default, this feature is *disabled*.

Note: 1. The two configuration items IP Address and Default Gateway cannot be the same for NET 1 and NET 2.

2. By default, *Speed and Duplex Mode* is hidden, set to Automatic Detection, you can click 'F' to let it display. We suggest you do not modify it because the non-automatic detection may cause abnormality in network interface.

If the Network Detect feature is enabled, a ping test will automatically be initiated from this IP address to the gateway to check the connection status between them. By default, this feature is disabled.

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations. After changing the IP address, you shall log in the gateway again using your new IP address.

3.12.2 Management

Management Parameters

WEB Management

WEB Port

80

Access Setting

IPs in Whitelist

201.123.115,201.123.113

IP addresses are separated by ','

IP Address

SSH Management Config

SSH

☒ Yes ☐ No

SSH Port

22

Remote Data Capture Config

Remote Data Capture

☐ Yes ☒ No

SYSLOG Parameters

SYSLOG

☒ Yes ☐ No

Server Address

127.0.0.1

SYSLOG Level

ERROR

CDR Parameters

Send CDR

☒ Yes ☐ No

Server Address

127.0.0.1

Server Port

3

NAT Parameters

Monitor Self-adaption

☐ Yes ☒ No

Debug Tool Self-adaption

☐ Yes ☒ No

Time Parameters

NTP

☒ Yes ☐ No

NTP Server Address

127.0.0.1

Synchronizing Cycle

3600

s

Daily Restart

☒ Yes ☐ No

Restart Time

7

h

13

m

System Time

☐ Modify

2015-08-19 12:58:11

Time Zone

GMT+8:00 (Beijing, Singapore, Taipei, Kuala Lumpur)

Save

Reset

Figure 3-118 Management Parameters Setting Interface

See Figure 3-118 for the Management Parameters Setting interface. The table below explains the items shown in the above figure.

Item	Description
------	-------------

WEB Port	The port which is used to access the gateway via WEB. The default value is 80.
Access Setting	Sets the IP addresses which can access the gateway via WEB. By default, all IPs are allowed. You can set an IP whitelist to allow all the IPs within it to access the gateway freely. Also you can set an IP blacklist to forbid all the IPs within it to access the gateway.
SSH	Sets whether to enable the gateway to be accessed via SSH, with the default value of <i>No</i> .
SSH Port	The port which is used to access the gateway via SSH.
Remote Data Capture	After this feature is enabled, you can obtain the gateway data via a remote capture tool. The default value is <i>No</i> .
SYSLOG	Sets whether to enable SYSLOG. It is required to fill in SYSLOG Server Address and SYSLOG Level in case SYSLOG is enabled. By default, SYSLOG is disabled.
Server Address	Sets the SYSLOG server address for log reception.
SYSLOG Level	Sets the SYSLOG level. There are three options: <i>ERROR</i> , <i>WARNING</i> and <i>INFO</i> .
Send CDR	Sets whether to enable the feature of sending CDR. It is required to fill in Server Address and Server Port in case Send CDR is enabled. By default, Send CDR is disabled.
Server Address	The address of the server to receive CDR.
Server Port	The port of the server to receive CDR.
Monitor Self-adaption	Enable the NAT stun between the gateway and the monitor tool. By default, it is disabled.
Debug Tool Self-adaption	Enable the NAT stun between the gateway and the debug tool. By default, it is disabled.
NTP	Sets whether to enable the NTP time synchronization feature. It is required to fill in NTP Server Address , Synchronizing Cycle and Time Zone in case NTP is enabled. By default, NTP is disabled.
NTP Server Address	Sets the Server address for NTP time synchronization.
Synchronizing Cycle	Sets the cycle for NTP time synchronization.
Daily Restart	Sets whether to restart the gateway regularly every day at the preset Restart Time . By default, this feature is disabled.
Restart Time	Sets the time to restart the gateway regularly.
System Time	The system time. Check the checkbox before Modify and change the time in the edit box.
Time Zone	The time zone of the gateway.

3.12.3 IP Routing Table

IP Routing Table is used to set the route for the LAN port when two network ports both transport SIP. Thus, the LAN can access some IPs in other different network segment. By default, there is no routing table available on the gateway, click **Add New** to add them manually. See Figure 3-119.

Routing Table

No.:

0

Destination:

Subnet Mask:

Network Port:

NET 1

▼

Save

Close

Figure 3-119 Routing Table Adding Interface

The table below explains the items shown in above figures.


Item	Description
No.	The number of the routing for the LAN in routing table.
Destination	The network segment the in which the IP address is accessible for the network port.
Subnet Mask	The subnet mask of the network segment.
Network Port	The corresponding network port of the routing.

After configuration, click **Save** to save the settings into the gateway or click **Close** to cancel the settings. See Figure 3-120 for the Routing Table List.

[illegible]

Figure 3-120 Routing Table List

Click **Modify** in Figure 3-120 to modify a routing. See Figure 3-121 for the routing table modification interface. The configuration items on this interface are the same as those on the **Add Routing Table** interface. Note that the item **No.** cannot be modified.




The image shows a 'Routing Table' configuration window. It has a title bar 'Routing Table'. Inside, there are four input fields: 'No.' with value '0', 'Destination' with value '201.123.112.0', 'Subnet Mask' with value '255.255.255.0', and 'Network Port' with a dropdown menu showing 'NET 1'. At the bottom, there are two buttons: 'Save' and 'Close'.

Figure 3-121 Routing Table Modification Interface

To delete a routing, check the checkbox before the corresponding index in Figure 3-120 and click the **Delete** button. To clear all number manipulation rules at a time, click the **Clear All** button in Figure 3-120.

3.12.4 SNMP Config



The image shows an 'SNMP Configuration' window. It has a title bar 'SNMP Configuration'. Inside, there are two sections: 'SNMP Configuration' and 'Community String Configuration'. Under 'SNMP Configuration', there is a checkbox 'Enable SNMP' which is unchecked, and two input fields: 'SNMP Server Address' with value '127.0.0.1' and 'Monitoring Port' with value '161'. Under 'Community String Configuration', there is an input field 'Access Password'. At the bottom, there are two buttons: 'Save' and 'Reset'.

Figure 3-122 SNMP Configuration Interface


See Figure 3-122 for the SNMP configuration interface. If the SNMP feature is enabled, once the gateway receives a request from the SNMP management software, it will collect relevant information and reply to the SNMP management software. By default, the SNMP feature is disabled. The available information includes kernel version, CPU usage, processes, memory usage, startup information, LAN status and etc. Currently, the gateway only provides the community string for information acquisition.

The table below explains the configuration items shown in the above figure.

Item	Description
SNMP Server Address	IP address of SNMP.
Monitoring Port	Monitoring Port for SNMP on the gateway.
Access Password	Community string used for information acquisition.

You can query OID (object identification trees) = .1.3.6.1.4.1.2021.51 at the SNMP Client to obtain the signaling link status and the line synchronization information,

3.12.5 Radius



The image shows a 'Radius Configuration' window with the following settings:

- Radius:** ☐ Enable
- Certification:** ☒ enable
- Allow Calls even if Server doesn't Respond:** ☐ enable
- Master Server:** 127.0.0.1:1813
- Shared Key:** [Masked with dots]
- Spare Server:** [Empty field]
- Shared Key:** [Empty field]
- Timeout (s):** 3
- Retransmission Times:** 1
- Transmit Interval of Charge Alive Package (s):** 20
- Call Type (Records Output Required):**
 - ☐ PSTN->IP
 - ☐ IP->PSTN
 - ☐ Conversation Start
 - ☐ Access Failure

At the bottom are 'Save' and 'Reset' buttons.

Figure 3-123 Radius Configuration Interface

See Figure 3-123 for the Radius Configuration interface. The Radius feature is supported. Once it is enabled, the gateway will serve as the Radius client and send messages to the Radius server at the start and end of each call to fulfill the charge business.

The table below explains the configuration items shown in the above figure.

Item	Description
Radius	Sets whether to enable Radius or not, with the default setting of <i>disabled</i> .
Certification	Sets whether to send the certification message before sending the charge message, with the default setting of <i>enabled</i> .
Allow Calls even if Server doesn't Respond	Once this feature is enabled, the calls will be allowed even if the Radius server doesn't respond the certification message. The default value is <i>disabled</i> .
Master Server	Sets the IP address and port of the master Radius server. Note: If the port isn't designated, the default port 1813 will be used.

Shared Key	<p>Sets the shared key used for the communication encryption between the master Radius server and the Radius client.</p> <p>Note: The key should be appointed by both the client and the server end ahead of time, and be configured the same at both sides.</p>										
Spare Server	<p>Sets the IP address and the port of the spare Radius server which will be automatically started upon the occurrence of malfunction on the communications between the gateway and Radius master server.</p> <p>Note: If the port isn't designated, the default port 1813 will be used.</p>										
Timeout	<p>Sets the maximum time to wait for the response after the message is sent out by Radius, with the default value of 3s. To guarantee the accuracy of the charge, the gateway will start the message retransmission mechanism once the charge message sent from the gateway to the Radius server is timeout without any response.</p>										
Retransmission Times	<p>Sets the retransmission times on no response to the Radius message, with the default value of 3.</p>										
Transmit Interval of Charge Alive Package	<p>Sets the transmit interval of the charge alive package, calculated by s. Range of value: 20~300, with the default value of 20.</p>										
Call Type (Records output required)	<p>Sets the type of calls which are required to output call records, including four options: PSTN→IP, IP→PSTN, conversion start and access failure.</p> <table border="1"> <thead> <tr> <th>Type</th><th>Meaning</th></tr> </thead> <tbody> <tr> <td>PSTN→IP</td><td>Whether to send the Radius charge message for the calls from PSTN to IP</td></tr> <tr> <td>IP→PSTN</td><td>Whether to send the Radius charge message for the calls from IP to PSTN</td></tr> <tr> <td>Conversion Start</td><td>Whether to send the record of the initial conversion, that is, whether to have the gateway send the record information about the initial conversion to the Radius server upon the connection of the conversion.</td></tr> <tr> <td>Access Failure</td><td>Whether to send the record of the calls in access failure, that is, whether to have the gateway send the record information about the calls in access failure to the Radius server upon the access failure occurs.</td></tr> </tbody> </table>	Type	Meaning	PSTN→IP	Whether to send the Radius charge message for the calls from PSTN to IP	IP→PSTN	Whether to send the Radius charge message for the calls from IP to PSTN	Conversion Start	Whether to send the record of the initial conversion, that is, whether to have the gateway send the record information about the initial conversion to the Radius server upon the connection of the conversion.	Access Failure	Whether to send the record of the calls in access failure, that is, whether to have the gateway send the record information about the calls in access failure to the Radius server upon the access failure occurs.
Type	Meaning										
PSTN→IP	Whether to send the Radius charge message for the calls from PSTN to IP										
IP→PSTN	Whether to send the Radius charge message for the calls from IP to PSTN										
Conversion Start	Whether to send the record of the initial conversion, that is, whether to have the gateway send the record information about the initial conversion to the Radius server upon the connection of the conversion.										
Access Failure	Whether to send the record of the calls in access failure, that is, whether to have the gateway send the record information about the calls in access failure to the Radius server upon the access failure occurs.										

After configuration, click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

3.12.6 Configuration File




Figure 3-124 Configuration File Interface

See Figure 3-124 for the Configuration File interface, including three files: SMGConfig.ini, ShConfig.ini and Ss7Server.ini. You can check and modify the items in these configuration files through this interface. Configurations about the gateway server, such as route rules, number manipulation, number filter and so on, are included in SMGConfig.ini; Configurations about the board are included in ShConfig.ini; and configurations about the SS7 server are included in Ss7Server.ini. You can modify these configurations on the interface directly, and then click **Save** to save the above settings into the gateway or click **Reset** to restore the configurations.

3.12.7 Signaling Capture

The interface is divided into four main sections, each with a blue header bar:

- Data Capture:**
 - Choose a network interface to capture data: LAN 1(201.123.112.26) [dropdown]
 - ☐ Capture RTP
 - Destination Address for Syslog: 201.123.112.254 [text box]
 - Buttons: Start, Stop
- TS Recording:**
 - Choose a port and a time slot to record data: Port 1 [dropdown], E1 Time Slot 0(T1 Time Slot 0) [dropdown]
 - Buttons: Start, Stop
 - Choose a port and a time slot to record data: Port 1 [dropdown], E1 Time Slot 16 [dropdown]
 - Buttons: Start, Stop
- E1 Two-way Recording:**
 - Choose a port and a time slot to record data: Port 1 [dropdown], E1 Time Slot 0(T1 Time Slot 0) [dropdown]
 - Buttons: Start, Stop
 - Choose a port and a time slot to record data: Port 1 [dropdown], E1 Time Slot 16 [dropdown]
 - Buttons: Start, Stop
- IP Two-way Recording:**
 - Choose a channel group and channel to record data: [dropdown], Channel 0 [dropdown]
 - Buttons: Start, Stop
 - Choose a channel group and channel to record data: [dropdown], Channel 16 [dropdown]
 - Buttons: Start, Stop

At the bottom of the interface are two buttons: Clean Data and Download Log.

Figure 3-125 Signaling Capture Interface

See Figure 3-125 for the Signaling Capture interface. Data Capture is used to capture data on the network interface you choose. Click **Start** to start capturing data (1024000 packets at most) on the corresponding network interface. SIP, ISDN, SS7 and SysLog are supported at present. You can enter the Syslog destination address to send Syslog to wherever required. Click **Stop** to stop data capture and download the captured packets.

Data Recording (one-way) and E1 Two-way Recording (two-way) are used to record data on the time slot you choose. Click **Start** to start recording data (maximum consecutively recording time: data recording is 100 minutes and two-way recording is 1 minutes) on the corresponding port and time slot. Click **Stop** to stop data recording and download the recorded data.

IP Two-way Recording is used to make recording of a designated channel in a specified channel group. Click **Start** to start recording data: Click **Stop** to stop data recording and download the recorded data.

Click **Clean Data** to clean all the recording files and captured packages. Click **Download Log** to download such logs as core files, configuration files, error information and so on.

3.12.8 Signaling Call Test

Signaling Call Test

Test Type: IP->PSTN

SIP Trunk Group No.: SIP Trunk Group[0]

CallerID:

CalledID:

Original CalleeID:

Start Clear

Signaling Trace

```

chid=0514,chid=0006,112->2222 CALL_ID= stat change:
GWS_OUT_MAKE_CALL-->GWS_OUT_WAIT_CALL_RESULT
chid=0006,chid=0514,112->2222 CALL_ID= stat change:
GWS_IDLE-->GWS_IN_SEND_RING
chid=0514,chid=0006,112->2222 CALL_ID= stat change:
GWS_OUT_WAIT_CALL_RESULT-->GWS_OUT_WAIT_CONNECT
chid=0006,chid=0514,112->2222 CALL_ID= stat change:
GWS_IN_SEND_RING-->GWS_IN_WAIT_OUT_CONNECT
chid=0006,chid=0514,112->2222 CALL_ID= stat change:
GWS_IN_WAIT_OUT_CONNECT-->GWS_IN_SEND_PICKUP
chid=0514,chid=0006,112->2222 CALL_ID= stat change:
GWS_OUT_WAIT_CONNECT-->GWS_OUT_CONNECTED
chid=0006,chid=0514,112->2222 CALL_ID= stat change:
GWS_IN_SEND_PICKUP-->GWS_IN_CONNECTED
ch=514 Rcv DTMF 1
ch=514 Rcv DTMF 1
ch=514 Rcv DTMF 4

```

Figure 3-126 Signaling Call Test Interface

See Figure 3-126 for the Signaling Call Test interface. This feature can help to test whether the route and the number manipulation already configured are proper or not, and whether the call can succeed or not.

The table below explains the configuration items shown in the above figure.

Item	Description
Test Type	The source trunk type for signaling call test. There are three options: IP→PSTN , PSTN→IP and PSTN Call Out
SIP Trunk Group No.	The SIP trunk group number you are required to select if choosing IP→PSTN in Test Type .
PCM Trunk Group No.	The PCM trunk group number you are required to select if choosing PSTN→IP in Test Type .
CallerID	The CallerID for the signaling call test.
CalleeID	The CalleeID for the signaling call test.
Original CalleeID	The original CalleeID for the signaling call test.

PCM Port	You are required to select the PCM port if choosing PSTN Call Out in Test Type , Note: This item will appear only if you choose PSTN Call Out in Test Type ,
PCM Channel	You are required to select the PCM channel if choosing PSTN Call Out in Test Type , Note: This item will appear only if you choose PSTN Call Out in Test Type ,
DTMF	You can select this item to send DTMFs after the establishment of call conversation on the channel for call test, if choosing PSTN Call Out in Test Type , Note: This item will appear only if you choose PSTN Call Out in Test Type ,
Signaling Trace	The information returned during the signaling call test, helping you to learn the detailed information about the test call.

After configuration, click **Start** to execute the signaling call test; click **Clear** to clear the signaling trace information.

Note: The call test will be finished only if the called party ends it. That is, the gateway can not stop the testing.

3.12.9 Signaling Call Track




Figure 3-127 Call Track Interface

See Figure 3-127 for the Call Track Interface, including three modes: Filter CallerID, Filter CalleeID and Filter None. This is mainly used to output and save call information, facilitating call trace and problem debugging. Click **Start** to track calls, and the trace logs will be shown in the “Track Message” field; click **Stop** to stop the call track; click **Filter** to filter the trace logs according to the condition you set; click **Clear** to clear all trace logs; click **download** to download trace logs.

3.12.10 PING Test





Figure 3-128 Ping Test Interface

See Figure 3-128 for the Ping Test interface. A Ping test can be initiated from the gateway on a designated IP address to check the connection status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Source IP Address	Source IP address where the Ping test is initiated.
Destination Address	Destination IP address on which the Ping test is executed.
Ping Count	The number of times that the Ping test should be executed. Range of value: 1~100.
Package Length	Length of a data package used in the Ping test. Range of value: 56~1024 bytes.
Info	The information returned during the Ping test, helping you to learn the network connection status between the gateway and the destination address.

After configuration, click **Start** to execute the Ping test; click **End** to terminate it immediately.

3.12.11 TRACERT Test



The image shows a web-based interface titled "Tracert Test". It contains three input fields: "Source IP Address" with a dropdown menu showing "LAN 1: 201.123.112.26", "Destination Address" with a text box containing "127.0.0.1", and "Maximum Jumps (1-255)" with a text box containing "30". Below these fields are two buttons: "Start" and "End". At the bottom, there is a section labeled "Info" with a large, empty text area for displaying test results.

Figure 3-129 Tracert Test Interface

See Figure 3-129 for the Tracert Test interface. A Tracert test can be initiated from the gateway on a designated IP address to check the routing status between them. The table below explains the configuration items shown in the above figure.

Item	Description
Source IP Address	Source IP address where the Tracert test is initiated.
Destination Address	Destination IP address on which the Tracert test is executed.
Maximum Jumps	Maximum number of jumps between the gateway and the destination address, which can be returned in the Tracert test. Range of value: 1~255.
Info	The information returned during the Tracert test, helping you to learn the detailed information about the jumps between the gateway and the destination address.

After configuration, click **Start** to execute the Tracert test; click **End** to terminate it immediately.

3.12.12 Modification Record





Figure 3-130 Modification Interface

The Modification Record interface is used to check the modification record on the web configuration. Click **Check** and the modification record will be shown on the dialog box. See Figure 3-130. Click **Download** to download the record file.

3.12.13 Backup & Upload



Data Backup

Choose a file to backup: Click the 'Backup' button on the right to backup the file.

Data Upload

To upload a file, select it and click the button 'Upload' on the right to start.


Choose a file to upload:

Note: Please edit the CSV file with Notepad.

Figure 3-131 Backup & Upload Interface

See Figure 3-131 for the Backup and Upload interface. To back up data to your PC, you shall first choose the file in the pull-down list and then click **Backup** to start. To upload a file to the gateway, you shall first choose the file type in the pull-down list, then select it via **Browse...**, and at last click **Upload**. The gateway will automatically apply the uploaded data to overwrite the current configurations.

3.12.14 Factory Reset



Factory Reset

Click the button 'Reset' below to restore to factory settings.

Figure 3-132 Factory Reset Interface

See Figure 3-132 for the Factory Reset interface. Click **Reset** to restore all configurations on the gateway to factory settings.

3.12.15 Upgrade

Current Version	
Serial Number	000000934
WEB	1.6.2_2015081416
Service	1.6.2_2015081416
Uboot	2.0.4_201411
Kernel	#350 SMP Wed Aug 5 09:46:48 CST 2015
Firmware	13

Select an Update File

Figure 3-133 Upgrade Interface

See Figure 3-133 for the upgrade interface where you can upgrade the WEB, gateway service, kernel and firmware to new versions. Select the upgrade package “*.tar.gz” via **Browse...** and click **Update** (The gateway will do MD5 verification before upgrading and will not start to upgrade until it passes the verification). Wait for a while and the gateway will finish the upgrade automatically. Note that clicking **Reset** can only delete the selected update file but not cancel the operation of **Update**.

3.12.16 Change Password

Change Password	
Current Username	<input type="text" value="admin"/>
Current Password	<input type="password"/>
New Username	<input type="text"/>
New Password	<input type="password"/>
Confirm New password	<input type="password"/>

Note: The username and the password can consist only of numbers, letters or the underline.

Figure 3-134 Password Changing Interface

See Figure 3-134 for the Password Changing interface where you can change username and password of the gateway. Enter the current password, the new username and password, and then confirm the new password. After configuration, click **Save** to apply the new username and password or click **Reset** to restore the configurations. After changing the username and password, you are required to log in again.

3.12.17 Device Lock



Figure 3-135 Device Lock Configuration Interface

See Figure 3-135 for the Device Lock Configuration interface. You can select at least one item as the condition to judge whether to lock the gateway or not, that is, as long as an item in the selected list is modified, the gateway will be locked. You shall enter the password which is necessary for device unlock. After your setting, click **Lock** and the device lock interface will be locked. See Figure 3-136. To unlock the interface, enter your password and click the **Unlock** button.



Figure 3-136 Unlock Device Interface

As long as an item in the selected list in Figure 3-135 is modified, the gateway will be locked. See Figure 3-137. In such case, only five pages including *system info*, *network setting*, *change password*, *device lock* and *restart* are available. Calls on both directions (from IP to PSTN and from PSTN to IP) will all be rejected. (The exception is, when the device is locked by Protocol, DPC or OPC being changed, calls will not be rejected until you restart the service.) Enter the device unlock interface (Figure 3-136) and input your password to unlock the device.



Figure 3-137 Device Lock Interface

3.12.18 Restart




Figure 3-138 Service/System Restart Interface

See Figure 3-138 for the Restart interface. Click **Restart** on the service restart interface to restart the gateway service or click **Restart** on the system restart interface to restart the whole gateway system.

Chapter 4 Typical Applications

4.1 Application 1



Note: In this application, we assume that Branch A, Branch B and the headquarter have established VLAN using VPN technology.

Figure 4-1 Application 1

In this application, calls within the enterprise, i.e. calls among the headquarters, Branch A and Branch B, are all carried via SIP without PSTN. Outbound calls from the enterprise are all processed by the PBX at the headquarters. This application provides an enterprise with a unified interface for outbound call communications, and facilitates their call recording management as well.

This section takes SMG2120 as an example and introduces the configurations for the gateway application with the following dialing plan:

Call from the headquarters to Branch A: 8+EXT (extension number)

Call from the headquarters to Branch B: 7+EXT

Make an outbound call from the headquarters: 0+Number

Call from Branch A to the headquarters: 9+EXT

Call from Branch A to Branch B: 7+EXT

Make an outbound call from Branch A: 0+Number

Call from Branch B to the headquarters: 9+EXT

Call from Branch B to Branch A: 8+EXT

Make an outbound call from Branch B: 0+Number

4.1.1 Configurations for Headquarters

1. Configure SIP Settings for the headquarters.

SIP Settings	
SIP Address of WAN	LAN 1: 201.123.112.26
Auto Change Default Gateway	<input type="checkbox"/> Enable
SIP Signaling Port	5060
Send 183 Message	<input checked="" type="checkbox"/> Enable
Obtain CallerID from	Username of From Field
Obtain CalleeID from	Request Field
Obtain Redirecting Number/Original CalleeID from Diversion Field	<input type="checkbox"/> Enable
NAT Traversal	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
SIP Encryption	<input type="checkbox"/> Enable
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Maximum Wait Answer Time (s)	60
Maximum Wait RTP Time (s)	0
Maximum Wait PSTN Resource Time(ms)	5000

Save Reset

Figure 4-2

2. Add the IP addresses of the gateways at Branch A and Branch B into the SIP trunks.

Check	Index	Remote Address	Remote Port	WAN Option	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List	Work
<input type="checkbox"/>	0	201.123.112.210	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24
<input type="checkbox"/>	1	201.123.114.212	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24

Figure 4-3

3. Add the SIP trunks at Branch A and Branch B into the corresponding SIP trunk groups.

Check	Index	SIP Trunks	SIP Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Branch_A	
<input type="checkbox"/>	1	1	Increase	Branch_B	

Figure 4-4

4. Set PCM.

PCM No.	Signaling Protocol	Clock	Signaling Time Slot	Signaling Link Type	Connection Line	Incoming Call Start TS, Amount	CRC-4	Modify
0	ISDN User Side	Line-synchronization	16	--	Twisted Pair Cable	--	Enable	
1	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
2	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
3	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	

Figure 4-5

5. Add PCM trunk

Check	Index	PCM NO.	Including Ts	Modify
<input type="checkbox"/>	0	0	1,2,3,4,5,6,7,9,10,11,13,16,17,19,20,21,23,24,25,27,28,29,30,31	

Figure 4-6

6. Add PCM trunk into the corresponding PCM trunk group.

Check	Index	PCM Trunks	PCM Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Headquarters	

Figure 4-7

7. Set routing parameters. You may adopt the default value 'Route before Number Manipulate' for both configuration items.

Route Settings	
IP->IP	Route before Number Manipulate
PSTN->IP	Route before Number Manipulate

Save

Figure 4-8

8. Set IP→PSTN routing rules to route calls from different SIP trunk groups to the corresponding PCM trunk groups. In this step, all incoming IP calls will be routed to PCM Trunk Group 0 regardless of the CalleeID prefix.



Figure 4-9

9. Set PSTN→IP routing rules to route calls from different PCM trunk groups to the corresponding SIP trunk groups. In this step, those calls with the CalleeID prefix 8 will be routed to SIP Trunk Group 0 while those with the CalleeID prefix 7 will be routed to SIP Trunk Group 1.




Figure 4-10

10. Set number manipulation rules. When the gateway receives a call from PSTN, it will first check the CalleeID prefix. If the CalleeID prefix is 7 or 8, the gateway will delete it before routing the call to the corresponding SIP trunk group.





Figure 4-11

4.1.2 Configurations for Branch A

1. Configure SIP Settings for Branch A.




SIP Settings

SIP Address of WAN	LAN 1: 201.123.112.26
Auto Change Default Gateway	<input type="checkbox"/> Enable
SIP Signaling Port	5060
Send 183 Message	<input checked="" type="checkbox"/> Enable
Obtain CallerID from	Username of From Field
Obtain CalleeID from	Request Field
Obtain Redirecting Number/Original CalleeID from Diversion Field	<input type="checkbox"/> Enable
NAT Traversal	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
SIP Encryption	<input type="checkbox"/> Enable
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Maximum Wait Answer Time (s)	60
Maximum Wait RTP Time (s)	0
Maximum Wait PSTN Resource Time(ms)	5000

Save Reset

Figure 4-12

- Add the IP addresses of the gateways at the headquarters and Branch B into the SIP trunks.



Check	Index	Remote Address	Remote Port	WAN Option	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List	Worki
<input type="checkbox"/>	0	201.123.112.210	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24
<input type="checkbox"/>	1	201.123.114.212	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24

Check All Uncheck All Inverse Delete Clear All Add New

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-13

- Add the SIP trunks at the headquarters and Branch B into the corresponding SIP trunk groups.




Check	Index	SIP Trunks	SIP Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Headquarters	
<input type="checkbox"/>	1	1	Increase	Branch_B	

Check All Uncheck All Inverse Delete Clear All Add New

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-14


- Set PCM.



PCM Settings								
PCM No.	Signaling Protocol	Clock	Signaling Time Slot	Signaling Link Type	Connection Line	Incoming Call Start TS,Amount	CRC-4	Modify
0	ISDN User Side	Line-synchronization	16	--	Twisted Pair Cable	--	Enable	
1	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
2	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
3	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	

Figure 4-15

5. Add PCM trunk




PCM Trunks				
Check	Index	PCM NO.	Including Ts	Modify
<input type="checkbox"/>	0	0	1,2,3,4,5,6,7,9,10,11,13,16,17,19,20,21,23,24,25,27,28,29,30,31	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-16

6. Add PCM trunk into the corresponding PCM trunk group.



PCM Trunk Group					
Check	Index	PCM Trunks	PCM Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Branch_A	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-17


7. Set routing parameters. You may adopt the default value 'Route before Number Manipulate' for both configuration items.



Route Settings	
IP->IP	Route before Number Manipulate
PSTN->IP	Route before Number Manipulate

Figure 4-18

8. Set IP→PSTN routing rules to route calls from different SIP trunk groups to the corresponding PCM trunk groups. In this step, all incoming IP calls will be routed to PCM Trunk Group 0 regardless of the CalleeID prefix.



Routing Rules								
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Number Filter	Call Destination	Description	Modify
<input type="checkbox"/>	63	SIP Trunk Group [0]	*	*	none	PCM Trunk Group [0]	from_HQ	
<input type="checkbox"/>	62	SIP Trunk Group [1]	*	*	none	PCM Trunk Group [0]	from_Branch_B	

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-19

9. Set PSTN→IP routing rules to route calls from different PCM trunk groups to the corresponding SIP trunk groups. In this step, those calls with the CalleeID prefix 9 or 0 will be routed to SIP Trunk Group 0 while those with the CalleeID prefix 7 will be routed to SIP Trunk Group 1.



Figure 4-20

10. Set number manipulation rules. When the gateway receives a call from PSTN, it will first check the CalleeID prefix. If the CalleeID prefix is 9 or 7, the gateway will delete it before routing the call to the corresponding SIP trunk group.




Figure 4-21

4.1.3 Configurations for Branch B

1. Configure SIP Settings for Branch B.

SIP Settings

SIP Address of WAN	LAN 1: 201.123.112.26
Auto Change Default Gateway	<input type="checkbox"/> Enable
SIP Signaling Port	5060
Send 183 Message	<input checked="" type="checkbox"/> Enable
Obtain CallerID from	Username of From Field
Obtain CalleeID from	Request Field
Obtain Redirecting Number/Original CalleeID from Diversion Field	<input type="checkbox"/> Enable
NAT Traversal	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
SIP Encryption	<input type="checkbox"/> Enable
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Maximum Wait Answer Time (s)	60
Maximum Wait RTP Time (s)	0
Maximum Wait PSTN Resource Time(ms)	5000

Save Reset

Figure 4-22

2. Add the IP addresses of the gateways at the headquarters and Branch A into the SIP trunks.

SIP Trunk

Check	Index	Remote Address	Remote Port	WAN Option	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List	Worki
<input type="checkbox"/>	0	201.123.112.210	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24
<input type="checkbox"/>	1	201.123.114.212	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24

Check All Uncheck All Inverse Delete Clear All Add New

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-23

3. Add the SIP trunks at the headquarters and Branch A into the corresponding SIP trunk groups.

SIP Trunk Group

Check	Index	SIP Trunks	SIP Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Headquarters	
<input type="checkbox"/>	1	1	Increase	Branch_A	

Check All Uncheck All Inverse Delete Clear All Add New

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-24

4. Set PCM.

PCM Settings								
PCM No.	Signaling Protocol	Clock	Signaling Time Slot	Signaling Link Type	Connection Line	Incoming Call Start TS,Amount	CRC-4	Modify
0	ISDN User Side	Line-synchronization	16	--	Twisted Pair Cable	--	Enable	
1	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
2	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	
3	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	

Figure 4-25

5. Add PCM trunk

PCM Trunks				
Check	Index	PCM NO.	Including Ts	Modify
<input type="checkbox"/>	0	0	1,2,3,4,5,6,7,9,10,11,13,16,17,19,20,21,23,24,25,27,28,29,30,31	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-26

6. Add PCM trunk into the corresponding PCM trunk group.

PCM Trunk Group					
Check	Index	PCM Trunks	PCM Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Branch_B	

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-27

7. Set routing parameters. You may adopt the default value 'Route before Number Manipulate' for both configuration items.

Route Settings	
IP->IP	Route before Number Manipulate
PSTN->IP	Route before Number Manipulate

Figure 4-28

8. Set IP→PSTN routing rules to route calls from different SIP trunk groups to the corresponding PCM trunk groups. In this step, all incoming IP calls will be routed to PCM Trunk Group 0 regardless of the CalleeID prefix.

Routing Rules								
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Number Filter	Call Destination	Description	Modify
<input type="checkbox"/>	63	SIP Trunk Group [0]	*	*	none	PCM Trunk Group [0]	from_HQ	
<input type="checkbox"/>	62	SIP Trunk Group [1]	*	*	none	PCM Trunk Group [0]	from_Branch_A	

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-29

9. Set PSTN→IP routing rules to route calls from different PCM trunk groups to the corresponding SIP trunk groups. In this step, those calls with the CalleeID prefix 9 or 0 will be routed to SIP Trunk Group 0 while those with the CalleeID prefix 8 will be routed to SIP Trunk Group 1.

Routing Rules									
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	Number Filter	Call Destination	Description	Modify	
<input type="checkbox"/>	63	PCM Trunk Group [0]	*	9	none	SIP Trunk Group [0]	to_HQ		
<input type="checkbox"/>	62	PCM Trunk Group [0]	*	8	none	SIP Trunk Group [1]	to_Branch_A		
<input type="checkbox"/>	61	PCM Trunk Group [0]	*	0	none	SIP Trunk Group [0]	to_PSTN		

3 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-30


10. Set number manipulation rules. When the gateway receives a call from PSTN, it will first check the CalleeID prefix. If the CalleeID prefix is 9 or 8, the gateway will delete it before routing the call to the corresponding SIP trunk group.

Number Manipulation Rules											
Check	Index	Call Initiator	CallerID Prefix	CalleeID Prefix	With Original CalleeID	Stripped Digits from Left	Stripped Digits from Right	Reserved Digits from Right	Prefix to Add	Suffix to Add	Description
<input type="checkbox"/>	63	PCM Trunk Group [0]	*	9	No	1	0	100			to_HQ
<input type="checkbox"/>	62	PCM Trunk Group [0]	*	8	No	1	0	100			to_Branch_A

2 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-31

4.2 Application 2



Note: In this application, we assume that Branch A, Branch B and the headquarters have established VLAN using VPN technology.

Figure 4-32 Application 2

In this application, the headquarters, Branch A and Branch B all have their own independent

digital gateways to connect with the PSTN. Calls within the enterprise are all carried via SIP. Outbound calls to PSTN can be allocated to different gateways by the IP PBX. This application makes a full use of each E1/T1 trunk, helps an enterprise to eliminate the single point failure caused by device or network malfunction and enhance the stability of the IP telephony network.

This section takes SMG2120 as an example and introduces the configurations for the gateway application with the following dialing plan:

Make an outbound call from the headquarters: 0+Number

Make an outbound call from Branch A or Branch B: 0+Number

4.2.1 Configurations for Headquarters

1. Configure SIP Settings for the headquarters.

SIP Settings

SIP Address of WAN	LAN 1: 201.123.112.26
Auto Change Default Gateway	<input type="checkbox"/> Enable
SIP Signaling Port	5060
Send 183 Message	<input checked="" type="checkbox"/> Enable
Obtain CallerID from	Username of From Field
Obtain CalleeID from	Request Field
Obtain Redirecting Number/Original CalleeID from Diversion Field	<input type="checkbox"/> Enable
NAT Traversal	<input type="checkbox"/> Enable
SIP Transport Protocol	UDP
SIP Encryption	<input type="checkbox"/> Enable
RTP Encryption	<input type="checkbox"/> Enable
RTP Self-adaption	<input type="checkbox"/> Enable
UDP Header Checksum	<input checked="" type="checkbox"/> Enable
Rport	<input type="checkbox"/> Enable
DSCP	<input type="checkbox"/> Enable
Calls from SIP Trunk Address only	<input type="checkbox"/> Enable
Switch Signal Port if SIP Registration Failed	<input type="checkbox"/> enable
Working Period	<input checked="" type="checkbox"/> 24 Hours
Maximum Wait Answer Time (s)	60
Maximum Wait RTP Time (s)	0
Maximum Wait PSTN Resource Time(ms)	5000

Save Reset

Figure 4-33

2. Add the IP address of the IP PBX into the SIP trunk.

SIP Trunk

Check	Index	Remote Address	Remote Port	WAN Option	Transport Protocol	Outgoing Voice Resource	Incoming Voice Resource	Voice Code List	Working Period
<input type="checkbox"/>	0	201.123.112.10	5060	NET 1	UDP	512	512	G711A,G711U,G729,G722,ILBC	24

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-34

3. Add the SIP trunk into the corresponding SIP trunk group.

Check	Index	SIP Trunks	SIP Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	IP_PBX	Edit

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-35

4. Set PCM.

PCM No.	Signaling Protocol	Clock	Signaling Time Slot	Signaling Link Type	Connection Line	Incoming Call Start TS, Amount	CRC-4	Modify
0	ISDN User Side	Line-synchronization	16	--	Twisted Pair Cable	--	Enable	Edit
1	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	Edit
2	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	Edit
3	ISDN User Side	Slave	16	--	Twisted Pair Cable	--	Enable	Edit

Figure 4-36

5. Add PCM trunk

Check	Index	PCM NO.	Including Ts	Modify
<input type="checkbox"/>	0	0	1,2,3,4,5,6,7,9,10,11,13,16,17,19,20,21,23,24,25,27,28,29,30,31	Edit

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-37

6. Add PCM trunk into the corresponding PCM trunk group.

Check	Index	PCM Trunks	PCM Trunk Select Mode	Description	Modify
<input type="checkbox"/>	0	0	Increase	Headquarters	Edit

Check All Uncheck All Inverse Delete Clear All Add New

1 Items Total 20 Items/Page 1/1 First Previous Next Last Go to Page 1 1 Pages Total

Figure 4-38

7. Set routing parameters. You may adopt the default value 'Route before Number Manipulate' for both configuration items.

Route Settings

IP->IP Route before Number Manipulate

PSTN->IP Route before Number Manipulate

Save

Figure 4-39

8. Set IP→PSTN routing rules to route calls from different SIP trunk groups to the corresponding PCM trunk groups. In this step, all incoming IP calls will be routed to PCM Trunk Group 0 regardless of the CalleeID prefix.




Figure 4-40

9. Set PSTN→IP routing rules to route calls from different PCM trunk groups to corresponding SIP trunk groups. In this step, all incoming calls from PSTN will be routed to SIP Trunk Group 0 regardless of the CalleeID prefix.




Figure 4-41

Note: In this application, the number manipulation feature is implemented by the IP PBX. That is, when a subscriber at the headquarters makes an outbound call dialing “0+Number”, the IP PBX will delete the prefix 0 before routing it to the gateway. Therefore, it is not necessary to configure the number manipulation rules on the gateway. However, you shall add to the IP PBX the number manipulation rule of deleting the CalleeID prefix 0.

4.2.2 Configurations for Branches

For the gateways at Branch A and Branch B, you shall fill in their actual IP addresses to the configuration item ‘SIP Address’. All the other configurations are the same as those for the headquarters.

Appendix A Technical Specifications

Dimensions

440×44×267 mm³

Weight

About 3.1 kg

Environment

Operating temperature: 0℃—45℃

Storage temperature: -20℃—85℃

Humidity: 8%— 90% non-condensing

Storage humidity: 8%— 90% non-condensing

LAN

Amount: 2 (10/100/1000 BASE-TX (RJ-45))

Self-adaptive bandwidth supported

Auto MDI/MDIX supported

E1/T1 Port

Amount: 1/2/4/8/16

Type: RJ45

Console Port

Amount: 1 (RS-232)

Baud rate: 115200bps

Connector: RJ45 (See [Hardware Description](#) for signal definition)

Data bits: 8 bits

Stop bit: 1 bit

Parity unsupported

Flow control unsupported

Note: Follow the above settings to configure the console port; or it may work abnormally.

Power Requirements

Input power: 100~240V AC

Maximum power consumption:

SMG2000 series: ≤12W

SMG3000 series: ≤22W

Signaling & Protocol

SS7: TUP, ISUP

ISDN: ISDN User Side, ISDN Network Side

SS1: SS1 Signaling

SIP signaling: SIP V1.0/2.0, RFC3261

Audio Encoding & Decoding

G.711A 64 kbps

G.711U 64 kbps

G.729A/B 8 kbps

G723 5.3/6.3 kbps

G722 64 kbps

AMR 4.75/5.15/5.90/6.70/7.40/7.9
5/10.20/12.20 kbps

iLBC 13.3/15.2 kbps

Sampling Rate

8kHz

Safety

Lightning resistance: Level 4

Appendix B Troubleshooting

1. What to do if I forget the IP address of the SMG digital gateway?

Long press the Reset button on the gateway to restore to factory settings. Thus the IP address will be restored to its default value:

LAN1: 192.168.1.101

LAN2: 192.168.0.101

2. In what cases can I conclude that the SMG digital gateway is abnormal and turn to Synway's technicians for help?

- a) During runtime, the run indicator does not flash or the alarm indicator lights up or flashes, and such error still exists even after you restart the device or restore it to factory settings.
- b) Voice problems occur during call conversation, such as that one party or both parties cannot hear the voice or the voice quality is unacceptable.
- c) The E1/T1 trunk of the gateway is well connected, but the E1/T1 indicators never light up after the gateway startup or their indications do not comply with the actual state.

Other problems such as abnormal PSTN trunk status, inaccessible calls, failed registrations and incorrect numbers are probably caused by configuration errors. We suggest you refer to [Chapter 3 WEB Configuration](#) for further examination. If you still cannot figure out or solve your problems, please feel free to contact our technicians.

3. What to do if I cannot enter the WEB interface of the SMG digital gateway after login?

This problem may happen on some browsers. To settle it, follow the instructions here to configure your browser. Enter 'Tools > Internet Options > Security Tab', and add the current IP address of the gateway into 'Trusted Sites'. If you change the IP address of the gateway, add your new IP address into the above settings.

Appendix C ISUP (ISDN) Pending Cause to SIP Status Code

ISUP (ISDN) Return Value	Cause	SIP Status Code	Implication
1	Unallocated (unassigned) number	404	Not found
2	No route to specified transit network	404	Not found
3	No route to destination	404	Not found
26	Non-selected user clearing	404	Not found
16	Normal call clearing (and the failure reason is that Waiting for off-hook signal from called party is overtime)	603	Decline
17	User busy	486	Busy here
132	Network busy (internal definition, only applies to ISDN)	486	Busy here
21	Call rejected	486	Busy here
18	No user responding	408	Request timeout
19	No answer from user (user alerted)	480	Temporarily unavailable
20	Subscriber absent	480	Temporarily unavailable
31	Normal, unspecified	480	Temporarily unavailable
136	Connection after pickup failed (internal definition, only applies to ISDN)	480	Temporarily unavailable
137	Pickup time out (internal definition, only apply to ISDN)	480	Temporarily unavailable
55	Incoming calls barred within CUG	403	Forbidden
57	Bearer capability not authorized	403	Forbidden
87	User not member of CUG	403	Forbidden
22	Number changed	410	Gone
27	Destination out of order	502	Bad gateway
28	Invalid number format	484	Address incomplete
29	Facility rejected	501	Not implemented
79	Service or option not implemented, unspecified	501	Not implemented
34	No circuit/channel available	503	Service unavailable
38	Network out of order	503	Service

			unavailable
41	Temporary failure	503	Service unavailable
42	Switching equipment congestion	503	Service unavailable
47	Resource unavailable, unspecified	503	Service unavailable
58	Bearer capability not presently available	503	Service unavailable
88	Incompatible destination	503	Service unavailable
133	Circuit restarted (internal definition, only applies to ISDN)	503	Service unavailable
134	Temporary fault (internal definition, only applies to ISDN)	503	Service unavailable
135	Data link failure (internal definition, only applies to ISDN)	503	Service unavailable
65	Bearer capability not implemented	488	Not acceptable here
70	Only restricted digital information bearer capability is available	488	Not acceptable here
102	Recovery on timer expiry	504	Server time-out
128	T303 time out (internal definition, only applies to ISDN)	504	Server time-out
129	T304 time out (internal definition, only applies to ISDN)	504	Server time-out
130	T310 time out (internal definition, only applies to ISDN)	504	Server time-out
111	Protocol error, unspecified	500	Server internal error
127	Interworking, unspecified	500	Server internal error
Others	Others	408	Request timeout

Appendix D TUP Pending Cause to SIP Status Code

TUP Return Value	Cause	SIP Status Code	Implication
11	SS7 signaling: receives SSB message from remote PBX	486	Busy here
12	SS7 signaling: receives SLB message from remote PBX	486	Busy here
13	SS7 signaling: receives STB message from remote PBX	486	Busy here
67	TUP: receives CBK message from remote PBX	403	Forbidden
21	SS7 signaling: receives ACB message from remote PBX	403	Forbidden
18	SS7 signaling: receives CFL message from remote PBX	403	Forbidden
14	SS7 signaling: receives UNN message from remote PBX	488	Not acceptable here
16	SS7 signaling: receives CGC message from remote PBX	406	Not acceptable
17	SS7 signaling: receives NNC message from remote PBX	406	Not acceptable
19	SS7 signaling: receives LOS message from remote PBX	406	Not acceptable
20	SS7 signaling: receives SST message from remote PBX	406	Not acceptable
22	SS7 signaling: receives DPN message from remote PBX	406	Not acceptable
23	SS7 signaling: receives EUM message from remote PBX	406	Not acceptable
24	SS7 signaling: receives ADI message from remote PBX	484	Address incomplete

Appendix E Technical/sales Support

Thank you for choosing Synway. Please contact us should you have any inquiry regarding our products. We shall do our best to help you.

Headquarters

Synway Information Engineering Co., Ltd

<http://www.synway.net/>

9F, Synway D&R Center, No.3756, Nanhuan Road, Binjiang District,
Hangzhou, P.R.China, 310053

Tel: +86-571-88860561

Fax: +86-571-88850923

Technical Support

Tel: +86-571-88864579

Mobile: +86-18905817070

Email: techsupport@sanhuid.com

Email: techsupport@synway.net

MSN: synway.support@hotmail.com

Sales Department

Tel: +86-571-88860561

Tel: +86-571-88864579

Fax: +86-571-88850923

Email: sales@synway.net